



# DIGI PLEX EVO

Keypad Modules  
Annunciator Module  
Motion Detector Modules  
Zone Expansion Modules  
Access Control Module  
Voice Assisted Modules  
Accessory Modules  
Integration Module  
Internet Module

## Modules Programming Guide

We hope this product performs to your complete satisfaction. Should you have any questions or comments, please visit [www.paradox.com](http://www.paradox.com) and send us your comments.

# Table of Contents

---

Modules Programming Guide .....	4
Grafica Graphic LCD Keypad Module .....	5
32-Character Blue LCD Keypad Module .....	7
48-Zone LED Keypad Module .....	11
Annunciator Module.....	13
Motion Detector Modules.....	14
Outdoor High-Security Digital Motion Detector Modules .....	15
360° Ceiling Mounted Motion Detector Module .....	16
Digital Glassbreak Detector .....	17
1-zone Expansion Module .....	18
4-zone Expansion Module .....	19
8-zone Expansion Module .....	20
Magellan Wireless Expansion Module.....	21
Listen-in Module .....	23
DGP-ACM12.....	26
4-PGM Expansion Module.....	28
Voice Assisted Arm/Disarm Module .....	29
Integration Module .....	30
Plug-In Voice Dialer .....	34
Module Connection Drawings.....	35
Appendix 1: Programming PGMs .....	46

## Entering Programming Mode

This programming guide should be used in conjunction with each module's *Reference & Installation Manual* which can be downloaded from our website at [paradox.com](http://paradox.com). Use this guide to record the settings programmed for these modules.

Use any keypad connected to the combus to access the programming mode.

- 1) Press and hold the **[0]** key.
- 2) Enter your **[INSTALLER CODE]**.
- 3) Key in section **[4003]** (EVO)
- 4) Enter the module's **[SERIAL NUMBER]**
- 5) Enter the required **[DATA]**.



### Feature Select Programming:

Some of the modules' sections are programmed by enabling or disabling options. Numbers **[1]** to **[8]** represent a specific option within the sections. Press the button corresponding to the desired option. The selected digit will appear on the LCD screen. This means that the option is enabled. Press the key again to remove the digit from the display thereby disabling the option. Press the **[ENTER]** button when the desired options are set.

### Decimal Programming:

Some module sections require that a decimal value be entered. E.g.: A PGM Timer will require a 3-digit time to be entered. With this method, any 3-digit number from 000 to 255 can be entered.

### Level Programming:

Some module sections are programmed using "Level Programming". In this section only one option can be enabled. To enable the option, use the  and  buttons until the option you want is illuminated, then press the **[ENTER]** button to set the option.

## Programming modules using other methods:

### WinLoad:

The modules can be programmed at 38,400 baud by connecting locally using a 307USB adapter or remotely through a modem.

### Modules Broadcast Feature:

Copy the contents of all programming sections from one module to one or more modules of the same type. To enter the programming mode, key in section **[4004]**. Enter the serial number of the source module, followed by the serial numbers of the modules you wish to program. To begin transferring data, press **[ACC]** on LCD keypads or the center action key (**Start**) on Grafica keypads.



## DNE-K07 V1.4

### Grafica Graphic LCD Keypad Module

Grafica Keypads can be used with DGP-848 and DGP-NE96 V1.3 or higher control panels and Digiplex EVO series control panels. Grafica will not function with DGP-48 control panels.

The keypad's serial number can be found on the keypad's PC board. The keypad's serial number can also be viewed by pressing and holding the **[0]** key, entering the **[INSTALLER CODE]** and then entering section **[000]**.

△ = Default setting

<b>Section [001] Keypad Partition Assignment</b>		
<b>Options</b>		
[1]	Partition 1	<b>OFF</b> <input type="checkbox"/> Disabled
[2]	Partition 2	<input type="checkbox"/> Disabled
[3]	Partition 3	<input type="checkbox"/> Disabled
[4]	Partition 4	<input type="checkbox"/> Disabled
[5]	Partition 5 (EVO 192 only)	<input type="checkbox"/> Disabled
[6]	Partition 6 (EVO 192 only)	<input type="checkbox"/> Disabled
[7]	Partition 7 (EVO 192 only)	<input type="checkbox"/> Disabled
[8]	Partition 8 (EVO 192 only)	<input type="checkbox"/> Disabled
		<b>ON</b> △ Enabled
		△ Enabled
		△ Enabled
		△ Enabled
		△ Enabled
		△ Enabled
		△ Enabled
		△ Enabled
<b>Section [002] System Options</b>		
<b>Options</b>		
[1]	Display Code Entry	<b>OFF</b> △ Disabled
[2]	Display Exit Delay	<input type="checkbox"/> Disabled
[3]	Display Entry Delay	<input type="checkbox"/> Disabled
[4]	Confidential Mode (not for UL installations)	△ Disabled
[5]	To exit Confidential Mode	△ Enter code
[6]	Exit Delay Beep	<input type="checkbox"/> Disabled
[7]	Keypad Input Type	<input type="checkbox"/> Temp. input
[8]	Keypad Tamper	△ Disabled
		<b>ON</b> <input type="checkbox"/> Enabled
		△ Enabled
		△ Enabled
		<input type="checkbox"/> Enabled
		<input type="checkbox"/> Press Button
		△ Enabled
		<input type="checkbox"/> Zone input
		<input type="checkbox"/> Enabled
<b>Section [003] Beep on Trouble</b>		
<b>Options</b>		
[1]	System & Clock Trouble Beep	<b>OFF</b> △ Disabled
[2]	Communicator Trouble Beep	△ Disabled
[3]	Module & Combus Trouble Beep	△ Disabled
[4]	All Zone Trouble Beep	△ Disabled
[5] to [8]	Future Use	<input type="checkbox"/> N/A
		<b>ON</b> <input type="checkbox"/> Enabled
		<input type="checkbox"/> Enabled
		<input type="checkbox"/> Enabled
		<input type="checkbox"/> Enabled
		<input type="checkbox"/> N/A
<b>Section [004] Confidential Mode Timer</b>		
[004]	___/___/___ (005 to 255 seconds; Default: 120 seconds)	
<b>Section [005] Outside Temperature Calibration</b>		
[005]	___/___/___ (000 to 254; 000 and 128 = no calibration value)	
<b>Section [006] Inside Temperature Calibration</b>		
[006]	___/___/___ (000 to 254; 000 and 128 = no calibration value)	

## Using the Memory Key

- [100]** Download all from the Memory Key (Grafica keypad sections **[001]** to **[006]** and all user, zone, door and area labels) to the Grafica keypad.
- [110]** Copy the Grafica keypad sections **[001]** to **[006]** and all user, zone, door and area labels to the Memory Key.


### Download Contents of the Memory Key to the Grafica Keypad:

- 1) Insert the Memory Key onto the keypad's connector (refer to *Memory Key Connector* on page 4).
- 2) To download the contents of the Memory Key, enter the keypad's programming mode and enter section **[100]**.
- 3) Once the keypad emits a confirmation beep, wait for a second confirmation beep and then remove the Memory Key.


### Copy Contents of the Grafica Keypad to the Memory Key:

- 1) Insert the Memory Key onto the keypad's connector (refer to *Memory Key Connector* on page 4). Ensure that the 'write protect' jumper is on (refer to *Memory Key* below).
- 2) To copy the contents to the Memory Key, enter the keypad's programming mode and enter section **[110]**.
- 3) Once the keypad emits a confirmation beep, wait for a second confirmation beep and then remove the Memory Key. Remove the Memory Key's jumper if you do not wish to accidentally overwrite its contents.

## Memory Key Connector



## Memory Key





## EVO641/EVO641R V1.08

### 32-Character Blue LCD Keypad Module

The keypad's serial number can be found on the keypad's PC board. The keypad's serial number can also be viewed by pressing and holding the **[0]** key, entering the **[INSTALLER CODE]** and then entering section **[000]**.

△ = Default setting

#### Section [001] Keypad Partition Assignment

##### Options

- [1] *Partition 1*
- [2] *Partition 2*
- [3] *Partition 3*
- [4] *Partition 4*
- [5] *Partition 5 (EVO192 only)*
- [6] *Partition 6 (EVO192 only)*
- [7] *Partition 7 (EVO192 only)*
- [8] *Partition 8 (EVO192 only)*

##### OFF

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

##### ON

- △ **Enabled**
- △ **Enabled**
- △ **Enabled**
- △ **Enabled**
- △ **Enabled**
- △ **Enabled**
- △ **Enabled**
- △ **Enabled**

#### Section [002] Assigning Doors to Partitions †

##### Options

- [1] *Door Assigned to Partition 1*
- [2] *Door Assigned to Partition 2*
- [3] *Door Assigned to Partition 3*
- [4] *Door Assigned to Partition 4*
- [5] *Door Assigned to Partition 5 (EVO192 only)*
- [6] *Door Assigned to Partition 6 (EVO192 only)*
- [7] *Door Assigned to Partition 7 (EVO192 only)*
- [8] *Door Assigned to Partition 8 (EVO192 only)*

##### OFF

- Disabled
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**

##### ON

- △ **Enabled**
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

#### Section [003] General Options 1

##### Options

- [1] *Display code entry*
- [2] *Display exit delay*
- [3] *Display entry delay*
- [4] *Confidential Mode (not for UL installations)*
- [5] *To exit Confidential Mode*
- [6] & [7] *Future Use*
- [8] *Time display option*

##### OFF

- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Enter code**
- N/A
- △ **yy/mm/dd**

##### ON

- Enabled
- Enabled
- Enabled
- Enabled
- Press Button
- N/A
- dd/mm/yy

#### Section [004] General Options 2

##### Options

- [1] *Muting*
- [2] *Exit Delay Beep*
- [3] *Door Left Open Pre-Alarm †*
- [4] *Chime on Zone Closure*
- [5] *Door Left Open Alarm Feedback †*
- [6] *Door Left Open Alarm Follows †*
- [7] *Door Forced Alarm †*
- [8] *Door Forced Alarm †*

##### OFF

- △ **Disabled**
- Disabled
- Disabled
- △ **Disabled**
- Silent
- △ **Alarm restore**
- Silent
- △ **Alarm restore**

##### ON

- Enabled
- △ **Enabled**
- △ **Enabled**
- Enabled
- △ **Audible**
- Beep Timer
- △ **Audible**
- Beep Timer

† Section/option is only available with 57

‡ Section/option is only available with EVO641

<b>Section [005]</b>	<b>Beep on Trouble</b>
<b>Options</b>	
[1]	System & Clock Trouble Beep
[2]	Communicator Trouble Beep
[3]	Module & Combus Trouble Beep
[4]	All Zone Trouble Beep
[5] to [6]	Future Use
[7]	Time Format
[8]	Future Use

<b>OFF</b>	<b>ON</b>
<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
<input checked="" type="checkbox"/> 24Hr clock	<input type="checkbox"/> 12Hr clock
<input type="checkbox"/> N/A	<input type="checkbox"/> N/A

<b>Section [006]</b>	<b>PGM and Tamper Options</b>
<b>Options</b>	
[1]	PGM State‡
[2]	PGM Deactivation Mode‡
[3]	PGM Base Time‡
[4]	PGM Override‡
[5]	Keypad Tamper
[6] to [8]	Future Use

<b>OFF</b>	<b>ON</b>
<input checked="" type="checkbox"/> N.O.	<input type="checkbox"/> N.C.
<input checked="" type="checkbox"/> Deactivation Event	<input type="checkbox"/> PGM Timer
<input checked="" type="checkbox"/> 1 second	<input type="checkbox"/> 1 minute
<input checked="" type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
<input checked="" type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
<input type="checkbox"/> N/A	<input type="checkbox"/> N/A

<b>Section [006]</b>	<b>General Options 3 †</b>
<b>Options</b>	
[1]	Card Activates Door Unlocked Schedule
[2]	Door Left Open Alarm
[3]	Door Forced Open Alarm
[4]	PIN Entry on Keypad (Option cannot be turned ON).
[5]	Keypad Tamper
[6]	Relock Door
[7]	Future Use
[8]	Unlock on REX

<b>OFF</b>	<b>ON</b>
<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
<input checked="" type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
<input checked="" type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
<input checked="" type="checkbox"/> Enabled	<input type="checkbox"/> N/A
<input checked="" type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
<input checked="" type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
<input checked="" type="checkbox"/> Disabled	<input type="checkbox"/> Enabled

Section	Data	Description	Default
[007]	__/__/__ (005 to 255 seconds)	Confidential Mode Timer	120
[008]	__/__/__ (000 to 255; see option [3] in section [006])	PGM Timer ‡	005
[008]	__/__/__ (000 to 255 seconds)	Door Unlocked Period †	005
[009]	__/__/__ (000 to 255 seconds added to section [008])	Door Unlocked Period Extension †	015
[010]	__/__/__ (000 to 255 seconds)	Door Left Open Interval †	060
[011]	__/__/__ (000 to 25 seconds)	Door Left Open Pre-Alarm Timer †	015
[012]	__/__/__ (000 to 25 seconds)	Beep Timer for Door Left Open Alarm †	005
[013]	__/__/__ (000 to 25 seconds)	Beep Timer for Door Forced Open Alarm †	005

**Section [017] Door Unlocked Schedule †**  
Start Time

End Time	Days (Turn ON or OFF)
_____ : _____	<b>S M T W T F S H</b>
_____ : _____	1 2 3 4 5 6 7 8
_____ : _____	1 2 3 4 5 6 7 8

Schedule A: \_\_\_\_\_ : \_\_\_\_\_

Schedule B: \_\_\_\_\_ : \_\_\_\_\_

† Section/option is only available with EVO641R.

‡ Section/option is only available with EVO641.

Sections ‡	PGM Activation Event
[009]	___/___/___ Event Group
[010]	___/___/___ Feature Group
[011]	___/___/___ Start #
[012]	___/___/___ End #

Sections ‡	PGM Deactivation Event
[013]	___/___/___ Event Group
[014]	___/___/___ Feature Group
[015]	___/___/___ Start #
[016]	___/___/___ End #

‡ Section/option is only available with EVO641.



Only Event Groups 000 to 055 and 070 can be used to program the module's PGM. Refer to Appendix 1: Programming PGMs on page 52 for the PGM Table.

## Message Programming

Each section from [101] to [148], [200] to [204] and [301] to [396] contains one message with a maximum of 16 characters. The sections contain the following messages:

Sections	[101] to [148] = "Zone 01" to "Zone 48" respectively
Section	[200] = "Paradox Security"
Sections	[201] to [204] = "First Area", "Second Area", "Third Area", and "Fourth Area"
Sections	[301] to [396] = "Code 01" to "Code 96" respectively

After entering the section corresponding to the desired message, the message can be re-programmed to suit your installation needs as detailed in Table 1. For example, section [101] "Zone 01" can be changed to "FRONT DOOR".



Use WinLoad to program a message for zones 49 to 192 and for codes 97 to 999 respectively.

Table 1: Message Programming Special Function Keys

Key	Function	Details
[stay]	Insert Space	Press the [STAY] key to insert a blank space at the current cursor's position.
[force]	Delete	Press the [FORCE] key to delete the character or blank space found at the current cursor's position.
[arm]	Delete Until the End	Press the [ARM] key to delete all characters and spaces to the right of the cursor and at the cursor's position.
[disarm]	Numeric/ Alphanumeric	Press the [DISARM] key to toggle the numeric keys to alphanumeric keys and vice versa. Numeric: Keys [0] to [9] represent numbers 0 to 9. Alphanumeric: refer to Table 2 below.
[byp]	Lower/Upper Case	Press the [BYP] key to toggle from lower to upper case and vice versa.
[mem]	Special Characters	After pressing the [MEM] key, the cursor will turn into a flashing black square. Using Table 3 below, enter the 3-digit number for the desired character.

Table 2: Alphanumeric Keys

Key	Press Key Once	Press Key Twice	Press Key Three Times
[1]	A	B	C
[2]	D	E	F
[3]	G	H	I
[4]	J	K	L
[5]	M	N	O
[6]	P	Q	R
[7]	S	T	U
[8]	V	W	X
[9]	Y	Z	N/A

Table 3: Special Characters


032	048	064	080	096	112	128	144	160	176	192	208	
	0	@	P	`	p	Ù	Ê	à	§	Ø	•	
033	049	065	081	097	113	129	145	161	177	193	209	
	1	A	Q	a	q	Û	Ë	â	±	Ł	ˆ	
034	050	066	082	098	114	130	146	162	178	194	210	
	2	B	R	b	r	Ú	É	í	ıj	Đ	°	
035	051	067	083	099	115	131	147	163	179	195	211	
	3	C	S	c	s	Ü	Ë	í	↑	ß	`	
036	052	068	084	100	116	132	148	164	180	196	212	
	4	D	T	d	t	Û	ê	ï	↓	ç	´	
037	053	069	085	101	117	133	149	165	181	197	213	
	5	E	U	e	u	ù	è	i	↵	®	~	
038	054	070	086	102	118	134	150	166	182	198	214	
	6	F	V	f	v	ú	é	ñ	f	¤	÷	
039	055	071	087	103	119	135	151	167	183	199	215	
	7	G	W	g	w	ô	ë	ñ	£	⌂	«	
040	056	072	088	104	120	136	152	168	184	200	216	
	8	H	X	h	x	ò	ä	Ñ	→	μ	»	
041	057	073	089	105	121	137	153	169	185	201	217	
	9	I	Y	i	y	ó	Ä	ğ	↵	Ø	!.	
042	058	074	090	106	122	138	154	170	186	202	218	
	*	J	Z	j	z	õ	á	9	↑	ÿ	\	
043	059	075	091	107	123	139	155	171	187	203	219	
	+	;	K	[	k	{	ô	â	v	↓	Ä	x
044	060	076	092	108	124	140	156	172	188	204	220	
	,	<	L	¥	l	l	ò	à	v	↑	ç	©
045	061	077	093	109	125	141	157	173	189	205	221	
	-	=	M	]	m	}	ó	á	w	½	ä	©
046	062	078	094	110	126	142	158	174	190	206	222	
	.	>	N	^	n	→	ö	ä	Ω	⅓	Ö	☐
047	063	079	095	111	127	143	159	175	191	207	223	
	/	?	O	_	o	←	ı	Ä	Æ	¼	ö	≡

## Using the Memory Key

- [510]** Download all from the Memory Key (LCD keypad sections **[001]** to **[396]** and all labels and messages) to the LCD keypad.
- [520]** Copy the LCD keypad sections **[001]** to **[396]** and all labels and messages to the Memory Key.


### Download Contents of the Memory Key to the LCD Keypad

- 1) Insert the Memory Key onto the keypad's connector labelled "KEY".
- 2) To download the contents of the Memory Key, enter the keypad's programming mode and enter section number.
- 3) Once the keypad emits a confirmation beep, wait for a second confirmation beep and then remove the Memory Key.




### Copy Contents of the LCD Keypad to the Memory Key

- 1) Insert Memory Key onto the keypad's connector labelled "KEY". Ensure that the 'write protect' jumper is on (refer to *Memory Key* below).
- 2) To copy the contents to the Memory Key, enter the keypad's programming mode and enter section number.
- 3) Once the keypad emits a confirmation beep, wait for a second confirmation beep and then remove the Memory Key. Remove the Memory Key's jumper if you do not wish to accidentally overwrite its contents.



## Memory Key



## Combus Voltmeter

To verify if the combus is supplying sufficient power, press and hold the **[0]** key, enter the **[INSTALLER CODE]** and press the **[ACC]** button. A reading of 10.5V or lower indicates that the voltage is too low. The voltage may drop during the control panel battery test.





## DGP2-648BL

### 48-zone LED Keypad Module

This model does not support installer programming capabilities, therefore you cannot program other modules or the panel on the combus using this unit.

Section	Data	Description	Default
[001]	_/_/_/ (000 to 004)*	Partition 1 Display	001 = (LED A1)
[002]	_/_/_/ (000 to 004)*	Partition 2 Display	002 = (LED A2)
[003]	_/_/_/ (000 to 004)*	Partition 3 Display	003 = (LED A3)
[004]	_/_/_/ (000 to 004)*	Partition 4 Display	004 = (LED A4)
[005]	_/_/_/ (000 to 004)*	Partition 5 Display	000
[006]	_/_/_/ (000 to 004)*	Partition 6 Display	000
[007]	_/_/_/ (000 to 004)*	Partition 7 Display	000
[008]	_/_/_/ (000 to 004)*	Partition 8 Display	000

\*000=disabled; 001=A1; 002=A2; 003=A3; 004=A4. Do not assign the same display number to more than one section. A maximum of 4 partitions can be displayed on the keypad.

△ = Default Settings

Section [009]	Keypad Options	OFF	ON
<b>Options</b>			
[1]	Confidential Mode	△ Disabled	<input type="checkbox"/> Enabled
[2]	Exit Confidential Mode	△ Press key	<input type="checkbox"/> Enter code
[3]	Muting	△ Disabled	<input type="checkbox"/> Enabled
[4]	Beep on Exit Delay	<input type="checkbox"/> Disabled	△ Enabled
[5]	Chime on Zone Closure	△ Disabled	<input type="checkbox"/> Enabled
[6] to [8]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A

Section [010]	Beep on Trouble	OFF	ON
<b>Options</b>			
[1]	Beep on System Trouble/Clock Loss	△ Disabled	<input type="checkbox"/> Enabled
[2]	Beep on Communicator Trouble	△ Disabled	<input type="checkbox"/> Enabled
[3]	Beep on Module/Combus Trouble	△ Disabled	<input type="checkbox"/> Enabled
[4]	Beep on Zone Trouble	△ Disabled	<input type="checkbox"/> Enabled
[5] to [8]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A

Section [011]	PGM & Keypad Tamper Options	OFF	ON
<b>Options</b>			
[1]	PGM State	△ N.O.	<input type="checkbox"/> N.C.
[2]	PGM Deactivation Mode	△ Deactivation Event	<input type="checkbox"/> PGM Timer
[3]	PGM Base Time	△ 1 second	<input type="checkbox"/> 1 minute
[4]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[5]	Keypad Tamper	△ Disabled	<input type="checkbox"/> Enabled
[6] to [8]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A

Sections	Data	Description	Default
[012]	__/__/__ (005 to 255 seconds)	Confidential Mode Timer	120
[013]	__/__/__ (001 to 255; see option [3] in section [011])	PGM Timer	005

Sections	PGM Activation Event
[014]	__/__/__ Event Group
[015]	__/__/__ Feature Group
[016]	__/__/__ Start #
[017]	__/__/__ End #

Sections	PGM Deactivation Event
[018]	__/__/__ Event Group
[019]	__/__/__ Feature Group
[020]	__/__/__ Start #
[021]	__/__/__ End #

 Refer to Appendix 1: Programming PGMs on page 52 for the PGM Table. Only Event Groups 000 to 055 can be used to program the module's PGM.


Sections	Description
[030]	<b>Test PGM:</b> Activates the PGM for 8 seconds to verify if the PGM is functioning properly.
[040]	<b>Zone Display Reset:</b> Resets zone display sections [101] to [196] to default values.

**Zone Display**

Section	LED Number	Zone Displayed	Default	Section	LED Number	Zone Displayed	Default	Section	LED Number	Zone Displayed	Default
[101]	_/_/_	Zone 1	001	[133]	_/_/_	Zone 33	033	[165]	_/_/_	Zone 65	000
[102]	_/_/_	Zone 2	002	[134]	_/_/_	Zone 34	034	[166]	_/_/_	Zone 66	000
[103]	_/_/_	Zone 3	003	[135]	_/_/_	Zone 35	035	[167]	_/_/_	Zone 67	000
[104]	_/_/_	Zone 4	004	[136]	_/_/_	Zone 36	036	[168]	_/_/_	Zone 68	000
[105]	_/_/_	Zone 5	005	[137]	_/_/_	Zone 37	037	[169]	_/_/_	Zone 69	000
[106]	_/_/_	Zone 6	006	[138]	_/_/_	Zone 38	038	[170]	_/_/_	Zone 70	000
[107]	_/_/_	Zone 7	007	[139]	_/_/_	Zone 39	039	[171]	_/_/_	Zone 71	000
[108]	_/_/_	Zone 8	008	[140]	_/_/_	Zone 40	040	[172]	_/_/_	Zone 72	000
[109]	_/_/_	Zone 9	009	[141]	_/_/_	Zone 41	041	[173]	_/_/_	Zone 73	000
[110]	_/_/_	Zone 10	010	[142]	_/_/_	Zone 42	042	[174]	_/_/_	Zone 74	000
[111]	_/_/_	Zone 11	011	[143]	_/_/_	Zone 43	043	[175]	_/_/_	Zone 75	000
[112]	_/_/_	Zone 12	012	[144]	_/_/_	Zone 44	044	[176]	_/_/_	Zone 76	000
[113]	_/_/_	Zone 13	013	[145]	_/_/_	Zone 45	045	[177]	_/_/_	Zone 77	000
[114]	_/_/_	Zone 14	014	[146]	_/_/_	Zone 46	046	[178]	_/_/_	Zone 78	000
[115]	_/_/_	Zone 15	015	[147]	_/_/_	Zone 47	047	[179]	_/_/_	Zone 79	000
[116]	_/_/_	Zone 16	016	[148]	_/_/_	Zone 48	048	[180]	_/_/_	Zone 80	000
[117]	_/_/_	Zone 17	017	[149]	_/_/_	Zone 49	000	[181]	_/_/_	Zone 81	000
[118]	_/_/_	Zone 18	018	[150]	_/_/_	Zone 50	000	[182]	_/_/_	Zone 82	000
[119]	_/_/_	Zone 19	019	[151]	_/_/_	Zone 51	000	[183]	_/_/_	Zone 83	000
[120]	_/_/_	Zone 20	020	[152]	_/_/_	Zone 52	000	[184]	_/_/_	Zone 84	000
[121]	_/_/_	Zone 21	021	[153]	_/_/_	Zone 53	000	[185]	_/_/_	Zone 85	000
[122]	_/_/_	Zone 22	022	[154]	_/_/_	Zone 54	000	[186]	_/_/_	Zone 86	000
[123]	_/_/_	Zone 23	023	[155]	_/_/_	Zone 55	000	[187]	_/_/_	Zone 87	000
[124]	_/_/_	Zone 24	024	[156]	_/_/_	Zone 56	000	[188]	_/_/_	Zone 88	000
[125]	_/_/_	Zone 25	025	[157]	_/_/_	Zone 57	000	[189]	_/_/_	Zone 89	000
[126]	_/_/_	Zone 26	026	[158]	_/_/_	Zone 58	000	[190]	_/_/_	Zone 90	000
[127]	_/_/_	Zone 27	027	[159]	_/_/_	Zone 59	000	[191]	_/_/_	Zone 91	000
[128]	_/_/_	Zone 28	028	[160]	_/_/_	Zone 60	000	[192]	_/_/_	Zone 92	000
[129]	_/_/_	Zone 29	029	[161]	_/_/_	Zone 61	000	[193]	_/_/_	Zone 93	000
[130]	_/_/_	Zone 30	030	[162]	_/_/_	Zone 62	000	[194]	_/_/_	Zone 94	000
[131]	_/_/_	Zone 31	031	[163]	_/_/_	Zone 63	000	[195]	_/_/_	Zone 95	000
[132]	_/_/_	Zone 32	032	[164]	_/_/_	Zone 64	000	[196]	_/_/_	Zone 96	000



*The keypad will display up to a total of 48 zones, however any zone from 1 to 96 can be selected. Do not assign more than one LED Number to a zone.*



# DGP2-ANC1B V1.1

## Annunciator Module

The DGP2-ANC1's serial number is located on the module's PC board.

△ = Default Settings

### Section [001] Partition Assignment

#### Options

- [1] Partition 1
- [2] Partition 2
- [3] Partition 3
- [4] Partition 4
- [5] Partition 5 (EVO192 only)
- [6] Partition 6 (EVO192 only)
- [7] Partition 7 (EVO192 only)
- [8] Partition 8 (EVO192 only)

#### OFF

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

#### ON

- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled

### Section [002] General Options 1

#### Options

- [1] Beeper Mute Mode\*
- [2] Beep on System Trouble
- [3] Beep on Communicator Trouble
- [4] Beep on Combustion/Module Trouble
- [5] Zone Trouble
- [6] to [8] Future Use

#### OFF

- △ Disabled
- △ Disabled
- △ Disabled
- △ Disabled
- △ Disabled
- N/A

#### ON

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- N/A

\* In order for options [2] to [5] to function, option [1] must be disabled.

### Sections

#### Status Display Mode

#### [003]

- \_\_/\_\_/\_\_ 000
- \_\_/\_\_/\_\_ 001
- \_\_/\_\_/\_\_ 002
- \_\_/\_\_/\_\_ 003 to 005

#### Description

- Partition Status
- Zones 01 to 48
- Zones 49 to 96
- Future Use

#### Default

- 000
- 000
- 000
- n/a

Enter a value between 000 and 005 to set which status the Annunciator will display.



## DGP2-50/60 & DGP2-70

### Motion Detector Modules

△ = Default Setting

#### Section [001] General Options

##### Options

		OFF	ON
[1]	Single/Dual Edge Processing	<input type="checkbox"/> Dual Edge	△ <b>Single Edge</b>
[2]	Alarm Indication (red LED illuminates for 5 secs.)	<input type="checkbox"/> Disabled	△ <b>Enabled</b>
[3]	Movement Signal Indication (red LED will flash)	<input type="checkbox"/> Disabled	△ <b>Enabled</b>
[4]	Non-movement Signal Indication (green LED will flash)	<input type="checkbox"/> Disabled	△ <b>Enabled</b>
[5]	Tamper Recognition	△ <b>Disabled</b>	<input type="checkbox"/> Enabled
[6] & [7] & [8]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A

Refer to DGP2-50/60/70's connection drawing on page 42 for the location of the DIP switches and Trimpot.

Section	Data	Description	Default
[002]	___/___/___	000 Very Low Shield, 001 Low Shield, 002 Normal Shield, 003 High Shield	002



## DG85 V1.3

### Outdoor High-Security Digital Motion Detector Modules

#### Operational Modes

The DG85 can function in two different operational modes: combus mode or relay mode. This option can only be configured using the **J3** jumper:

**Relay Mode: (DIP Switch 1 = OFF)**

When set to Relay Mode, the DG85 functions as would any standard motion detector by communicating its alarm and tamper signals via relays. The **GRN** and **YEL** terminals are not used in relay mode. In Relay Mode, the detector's settings can only be modified using the jumpers see table below.

**Combus Mode: (DIP Switch 1= ON)**

When set to combus mode, the DG85 communicates alarm signals, tamper signals, data and detector settings via the panel's 4-wire combus. The detector's relay output always remains active even when set to combus mode and can be used to activate other devices.

#### Settings

Refer to DG85's connection drawing on page 42 for the location of the DIP switches and Trimpot.

△ = Default Setting

Section [001]	General Options	OFF	ON	Manual Setting
<b>Options</b>				
[1]	Single/Dual Edge Processing	<input type="checkbox"/> Dual Edge	△ <b>Single Edge</b>	DIP Switch 2 OFF = Dual Edge ON = Single Edge
[2]	LED	<input type="checkbox"/> Disabled	△ <b>Enabled</b>	DIP Switch 3 OFF = Disabled ON = Enabled
[3]	Movement Signal Indication	<input type="checkbox"/> Disabled	△ <b>Enabled</b>	Enabled when DIP Switch 3 is ON
[4]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[5]	Tamper Recognition	△ <b>Disabled</b>	<input type="checkbox"/> Enabled	<input type="checkbox"/> N/A

Section	Data	Description	Default
[002]	___/___/___	000 Lowest Sensitivity, 010 Highest Sensitivity	Trimpot 0-10 <sup>4</sup>

To set the sensitivity manually, remove the front cover and, using a screwdriver, turn the trimpot clockwise to increase the detector's sensitivity or counter-clockwise to decrease it. You can turn the trimpot 360° in both directions. To determine the sensitivity setting, remove the cover and view how many times the LED flashes. The number of times the LED flashes corresponds to the sensitivity setting. Thus if the sensitivity is set to 6, the LED will flash 6 times

In instances where a particular setting can be set either manually or through section programming, a discrepancy may exist between the setting of the DIP switches and the setting in the appropriate sections. In such cases, the last change that is made will dictate the setting. For example, if you disable the LED from within section programming, the DIP switch will still show that it is enabled, however the LED is actually disabled.



# DG467 V1.0

## 360° Ceiling Mounted Motion Detector Module

### Operational Modes

The DG467 can function in two different operational modes: combus mode or relay mode. This option can only be configured using the **J4** jumper:

**Relay Mode: (J4 = OFF)**

When set to Relay Mode, the DG467 functions as would any standard motion detector by communicating its alarm and tamper signals via relays. The **GRN** and **YEL** terminals are not used in relay mode. In Relay Mode, the detector's settings can only be modified using the jumpers (see figure 1).

**Combus Mode: (J4 = ON)**

When set to combus mode, the DG467 communicates alarm signals, tamper signals, data and detector settings via the panel's 4-wire combus. The detector's relay output always remains active even when set to combus mode and can be used to activate other devices.

In combus mode, the motion detector can be modified using the jumpers or by entering module programming mode.



In combus mode, the DG467 will respect the most recent modification whether it is made through the jumpers or through section programming. As a result, current jumper positions may not represent actual settings. All settings are stored in the DG467 even after it has been powered down

△ = Default setting

Section [001]	General Options	OFF	ON	Manual Jumper Setting
<b>Options</b>				
[1]	Signal Processing Mode	<input type="checkbox"/> Dual Edge	△ <b>Single Edge</b>	OFF = Dual Edge J3 ON = Single Edge J3
[2]	LED Settings	<input type="checkbox"/> Disabled	△ <b>Enabled</b>	OFF= Disabled J1 ON = Enabled J1
[3]	Movement Without Alarm	<input type="checkbox"/> Disabled	△ <b>Enabled</b>	<input type="checkbox"/> N/A
[5]	Tamper Recognition	△ <b>Disabled</b>	<input type="checkbox"/> Enabled	<input type="checkbox"/> N/A

Section [002]	Status Display Mode	Description	Default	Manual Jumper Seeting
	__/__/__ 000	△ <b>Very low shield</b> (high sensitivity)		J2 <b>OFF</b> = High Shield
	__/__/__ 001	Low shield	n/a	J2 <b>ON</b> = △ <b>Very low shield</b>
	__/__/__ 002	Normal shield	n/a	n/a
	__/__/__ 003	High shield	n/a	n/a

Section [900]	Voltage Meter
	Displays <b>[3-digit number]</b> which represents input voltage x 10 e.g. <b>[133]</b> = 13.3V



## DG457 V1.0

### Digital Glassbreak Detector

#### Operational Modes

The DG457 can function in two different operational modes: combus mode or relay mode. This option can only be configured using the **J3** jumper:

##### Relay Mode: (J3 = OFF)

When set to Relay Mode, the DG457 functions as would any standard motion detector by communicating its alarm and tamper signals via relays. The **GRN** and **YEL** terminals are not used in relay mode. In Relay Mode, the detector's settings can only be modified using the jumpers (see figure 1).

##### Combus Mode: (J3 = ON)

When set to combus mode, the DG457 communicates alarm signals, tamper signals, data and detector settings via the panel's 4-wire combus. The detector's relay output always remains active even when set to combus mode and can be used to activate other devices.

In combus mode, the motion detector can be modified using the jumpers or by entering module programming mode.

△ = Default setting

Section [001]		OFF	ON	Manual Jumper Setting
<b>Options</b>				
[1]	<i>Sensitivity Setting</i>	△ <b>Regular</b>	<input type="checkbox"/> Low	OFF = Regular sensitivity J2 On = Low sensitivity J2
[2]	<i>Future Use</i>	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[3]	<i>Alarm Memory</i>	△ <b>Alarm disabled</b>	<input type="checkbox"/> Alarm Enabled	OFF = Alarm Disabled J1 ON = Alarm Enabled J1
[4]	<i>Future Use</i>	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[5]	<i>Tamper Recognition</i>	△ <b>Disabled</b>	<input type="checkbox"/> Enabled	<input type="checkbox"/> N/A

Section [002]	Test Mode
	<b>Keypad Method</b> Entering (123) initiates test mode.
	<b>Jumper Method</b> Remove and replace Jumper 1 (J1).
	<b>Test Trek Method</b> With the TestTrek unit (v2.0 or higher) approximately 2.5m (8ft) from the GlassTrek, hold the test button down. A beep followed by a series of beeps is produced which signals the GlassTrek to enter test mode.

Section [900]	Voltage Meter
	Displays [3-digit number] which represents input voltage x 10 e.g. [133] = 13.3V



# DGP2-ZX1 V2.0

## 1-zone Expansion Module



△ = Default setting

**Section [001]** General Options

**Option**

[1] *Tamper Recognition*

[2] to [8] *Future Use*

**OFF**

△ Disabled

N/A

**ON**

Enabled

N/A

Input speed = Base Time X Time Value (Default: 600ms)

**Sections**

**Base Time**



[002]

\_\_/\_\_/\_\_ (000 = 15 ms)

\_\_/\_\_/\_\_ (001 = 1second)

\_\_/\_\_/\_\_ (002 = 1 minute)

**Description**

*For the Base Time, using Level Programming, press the  and  buttons to select a value from 000 to 002 and then press [ENTER].*

**Default**

n/a

n/a

**Section**

**Time Value**

[003]

\_\_/\_\_/\_\_ (001 to 255)

# APR3-ZX4 V1.0

## 4-zone Expansion Module



△ = Default setting

### Section [001] General Options

#### Option

[1] Tamper Recognition ON = Input 4 (Z4) becomes tamper input

[2] to [8] Future Use

#### OFF

△ Disabled

N/A

#### ON

Enabled

N/A

Input Speed	Base Time (000-002)*	Time Value (000-255)	Default
Input 001	[002] ___/___/___	[003] ___/___/___	600ms
Input 002	[004] ___/___/___	[005] ___/___/___	600ms
Input 003	[006] ___/___/___	[007] ___/___/___	600ms
Input 004	[008] ___/___/___	[009] ___/___/___	600ms
Input 005 (ATZ of Input 001)	[010] ___/___/___	[011] ___/___/___	600ms
Input 006 (ATZ of Input 002)	[012] ___/___/___	[013] ___/___/___	600ms
Input 007 (ATZ of Input 003)	[014] ___/___/___	[015] ___/___/___	600ms
Input 008 (ATZ of Input 004)	[016] ___/___/___	[017] ___/___/___	600ms

\* For the Base Time, using Level Programming, press the and buttons to select a value from 000 to 002 and then press [ENTER]. Base Time Multipliers: 000 = 15 ms, 001 = 1 second, 002 = 1 minute.

# APR-ZX8

## 8-zone Expansion Module



△ = Default setting

<b>Section [001]</b>	General Options		
<b>Options</b>		<b>OFF</b>	<b>ON</b>
[1]	Tamper Recognition <i>ON = Input 8 (Z8) becomes tamper input</i>	△ Disabled	<input type="checkbox"/> Enabled
[2]	PGM Deactivation After	△ Disabled	<input type="checkbox"/> PGM Timer
[3]	PGM normal state	△ N.O.	<input type="checkbox"/> N.C.
[4]	PGM Base Time	△ 1 second	<input type="checkbox"/> 1 minute
[5] to [8]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A

Input Speed	Base Time (000-002)*	Time Value (000-255)	Default
001 or 009	[002] ___/___/___	[003] ___/___/___	600ms
002 or 010	[004] ___/___/___	[005] ___/___/___	600ms
003 or 011	[006] ___/___/___	[007] ___/___/___	600ms
004 or 012	[008] ___/___/___	[009] ___/___/___	600ms
005 or 013	[010] ___/___/___	[011] ___/___/___	600ms
006 or 014	[012] ___/___/___	[013] ___/___/___	600ms
007 or 015	[014] ___/___/___	[015] ___/___/___	600ms
008 or 016	[016] ___/___/___	[017] ___/___/___	600ms

\* For the Base Time, press the and buttons to select a value from 000 to 002 and then press [ENTER]. Base Time Multipliers: 000 = 15 ms, 001 = 1 second, 002 = 1 minute.

Section	Data	Description	Default
[018]	___/___/___ (000 to 255; see option [4] in section [001])	PGM Timer	005

Sections	PGM Activation Event
[019]	___/___/___ Event Group
[020]	___/___/___ Feature Group
[021]	___/___/___ Start #
[022]	___/___/___ End #

Sections	PGM Deactivation Event
[023]	___/___/___ Event Group
[024]	___/___/___ Feature Group
[025]	___/___/___ Start #
[026]	___/___/___ End #

Refer to Appendix 1: Programming PGMs on page 52 for the PGM Table. Only Event Groups 000 to 055 can be used to program the module's PGM.

Section	Description
[030]	<b>Test PGM:</b> Activates the PGM for 8 seconds to verify if the PGM is functioning properly.



## MG-RTX3 V1.1

### Magellan Wireless Expansion Module

When using on an EVO96 version 1.52 or higher without an EVO641, enable option [1] in section [3029].

△ = Default setting

#### Section [001]

##### Options

- [1] *Low battery supervision*
- [2] *Check-in supervision*
- [3] *Check-in supervision time interval*
- [4] *RF Jamming supervision*
- [5] *On-board module tamper*
- [6] & [7] *Future use*
- [8] *Transmitter tamper signal*

##### OFF

- Disabled
- △ **Disabled**
- △ **24 hours**
- Disabled
- △ **Disabled**
- N/A
- △ **Ignored**

##### ON

- Enabled
- Enabled
- 80 minutes
- △ **Enabled**
- Enabled
- N/A
- Reported

#### Section

- [030] View a transmitter's unknown 6-digit serial number

#### Sections

- [101] to [132] Assign the transmitters to the MG-RTX3 by entering their 6 digits serial numbers in the appropriate section or by pressing and releasing the transmitter's tamper switch.  
[101] = Transmitter/Input 1, [132] = Transmitter/Input 32  
To delete the assigned transmitters, enter 000000 as a serial number

#### Sections

##### Transmitter Info

- [601] to [632] View the transmitters' signal strength (3 or less is too weak and the transmitter should be moved, 4 to 10 is acceptable.) [601] is Transmitter/Input 1, [632] is Transmitter/Input 32)
- [701] to [732] View the current battery life of the transmitters (Number of weeks the batteries have been in the transmitter.) [701] is Transmitter/Input 1, [732] is Transmitter/Input 32)
- [801] to [832] View the previous battery life of the transmitters (Number of weeks the previous batteries were in the transmitter.) [801] is Transmitter/Input 1, [832] is Transmitter/Input 32)

##### Two-Way PGM

- [671] to [678] View Two-Way PGMs' signal strength. (3 or less is too weak and the transmitter should be moved, 4 to 10 is acceptable.)
- [901] to [908] Assign or delete Two-Way PGM (Enter the PGM's serial number or press and release the transmitter's tamper switch to assign it, or enter 000000 to delete it. Section [901] = PGM 1, section [908] = PGM 8. For [901] to [904], entering 000000 will assign it to the on-board PGM.)
- [910] to [989] Program the Two-Way PGM. (See Table 4 on page 21)

Table 4: PGM Option Programming

		Event Group	Feature Group	Start #	End #
PGM Activation*	PGM1	[910]	[911]	[912]	[913]
	PGM2	[920]	[921]	[922]	[923]
	-	+10 per PGM	+10 per PGM	+10 per PGM	+10 per PGM
	PGM8	[980]	[981]	[982]	[983]

PGM Deactivation*	PGM1	[914]	[915]	[916]	[917]
	PGM2	[924]	[925]	[926]	[927]
	-	+10 per PGM	+10 per PGM	+10 per PGM	+10 per PGM
	PGM8	[984]	[985]	[986]	[987]

\*For a complete list of events, refer to the PGM programming section of your Digiplex or Digiplex EVO control panel's programming guide.

		PGM Delay		Options
PGM Delay (000 to 255) Default: 005	PGM1	[918]	[919]	Option [1]: ON = PGM delay OFF = Latch (default)
	PGM2	[928]	[929]	
	-	+10 per PGM	+10 per PGM	Option [2]: ON = Minutes OFF = Seconds (default)
	PGM8	[988]	[989]	

**[991]** View Two-Way PGM tamper trouble (PGMs with the trouble will be indicated by their number)

**[992]** View Two-Way PGM supervision trouble (PGMs with the trouble will be indicated by their number)



### Sections

**[040] to [043]** View how many of the 32 remotes are used.  
[040] = remotes 1 to 8; [043] = remotes 25 to 32.  
To delete a remote, press the corresponding number until it's no longer displayed in these sections.

**[201] to [232]** Assigning remote controls to the MG-RTX3.  
[201] = remote 01; [232] = remote 32  
Enter the desired section and then press and hold a button on the remote control until you hear a confirmation beep.

**[301] to [332]** Assign the remote controls to users by entering a user number (001 to 255) in the appropriate section (Users 001 to 255, Section [301] = remote 01, section [332] = remote 32.)

Program the remote control or delete the remote control button programming.  
[401] = remote 01; [432] = remote 32

\_\_\_\_ / \_\_\_\_ / \_\_\_\_ / \_\_\_\_ / \_\_\_\_ / \_\_\_\_ / \_\_\_\_ / \_\_\_\_ (default: 15000000)  
 N/A N/A (see MG-REM1 instructions)  
 N/A N/A (see MG-REM2 instructions)

**[401] to [432]**

[0] = Button Disabled	[8] = Panic 2† (Non-Medical)
[1] = Regular Arm	[9] = Panic 3† (Fire)
[2] = Stay Arm	[stay] = Smoke reset
[3] = Instant Arm	[force] = Utility Key 1*
[4] = Force Arm	[arm] = Utility Key 2*
[5] = Disarm	[disarm] = Utility Key 3*
[6] = Stay/Instant Disarm	[byp] = Utility Key 4*
[7] = Panic 1† (Police)	[mem] = Utility Key 5*

[clear] = Exit without saving      [enter] = Save data

# DGP-LSN4 and DGP-SUB V1.1

## Listen-in Module



△ = Default setting

### Section [001] Substation 1 Partition Assignment

#### Options

- [1] *Partition 1*
- [2] *Partition 2*
- [3] *Partition 3*
- [4] *Partition 4*
- [5] *Partition 5*
- [6] *Partition 6*
- [7] *Partition 7*
- [8] *Partition 8*

#### OFF

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

#### ON

- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled

### Section [002] Substation 2 Partition Assignment

#### Options

- [1] *Partition 1*
- [2] *Partition 2*
- [3] *Partition 3*
- [4] *Partition 4*
- [5] *Partition 5*
- [6] *Partition 6*
- [7] *Partition 7*
- [8] *Partition 8*

#### OFF

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

#### ON

- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled

### Section [003] Substation 3 Partition Assignment

#### Options

- [1] *Partition 1*
- [2] *Partition 2*
- [3] *Partition 3*
- [4] *Partition 4*
- [5] *Partition 5*
- [6] *Partition 6*
- [7] *Partition 7*
- [8] *Partition 8*

#### OFF

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

#### ON

- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled

### Section [004] Substation 4 Partition Assignment

#### Options

- [1] *Partition 1*
- [2] *Partition 2*
- [3] *Partition 3*
- [4] *Partition 4*
- [5] *Partition 5*
- [6] *Partition 6*
- [7] *Partition 7*
- [8] *Partition 8*

#### OFF

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

#### ON

- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled

<b>Section [005]</b>	<b>General Option 1</b>		
<b>Options</b>		<b>OFF</b>	<b>ON</b>
[1]	Module Tamper Input	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[2]	Telephone Line Monitoring	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[3]	Volume Bypass	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[4]	Continuous Recording	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[5]	Bypass Siren on Communication	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[6]	Locate Feedback on Substations	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[7]	Response Connection Code	<input type="checkbox"/> Disabled	<input type="checkbox"/> Press *
[8]	Call Back Connection	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled

<b>Section [006]</b>	<b>General Option 2</b>		
<b>Options</b>		<b>OFF</b>	<b>ON</b>
[1]	Substation 1 Anti-tamper Switch	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[2]	Substation 2 Anti-tamper Switch	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[3]	Substation 3 Anti-tamper Switch	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[4]	Substation 4 Anti-tamper Switch	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[5]	Background Music Input	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[6]	User Phonenumber Menu Selection	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[7]	Monitoring Station Phonenumber Menu Selection	<input type="checkbox"/> Disabled	<input type="checkbox"/> Monitoring
[8]	User Phonenumber Default Menu	<input type="checkbox"/> Disabled	<input type="checkbox"/> Monitoring

<b>Section [007]</b>	<b>Connection Options 1</b>		
<b>Options</b>		<b>OFF</b>	<b>ON</b>
[1]	Zone Alarm starts Listen-in Mode	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[2]	Fire Alarm starts Listen-in Mode	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[3]	Duress Alarm starts Listen-in Mode	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[4]	Panic Police starts Listen-in Mode	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[5]	Panic Medical starts Listen-in Mode	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[6]	Panic Fire starts Listen-in Mode	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[7]	Zone Tamper starts Listen-in Mode	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[8]	Zone Supervision starts Listen-in Mode	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled

<b>Section [008]</b>	<b>Connection Options 2</b>		
<b>Options</b>		<b>OFF</b>	<b>ON</b>
[1]	Zone Fire Loop Trouble starts Listen-In Mode	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[2]	Module Tamper starts Listen-in Mode	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[3]	Door Force Alarm starts Listen-In Mode	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[4]	Bus Fault starts Listen-in Mode	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[5]	Police Code starts Listen-In Mode	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[6] - [8]	Future use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A

<b>Section [009]</b>	<b>Substation 1 Page Options</b>		
<b>Options</b>		<b>OFF</b>	<b>ON</b>
[1]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[2]	Substation 1 can page Substation 2	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[3]	Substation 1 can page Substation 3	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[4]	Substation 1 can page Substation 4	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[5] - [8]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A

<b>Section [010]</b>	<b>Substation 2 Page Options</b>		
<b>Options</b>		<b>OFF</b>	<b>ON</b>
[1]	Substation 2 can page Substation 1	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[2]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[3]	Substation 2 can page Substation 3	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[4]	Substation 2 can page Substation 4	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[5] - [8]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A

<b>Section [011]</b>	<b>Substation 3 Page Options</b>
<b>Options</b>	
[1]	Substation 3 can page Substation 1
[2]	Substation 3 can page Substation 2
[3]	Future Use
[4]	Substation 3 can page Substation 4
[5] - [8]	Future Use

- OFF**
- Disabled
  - Disabled
  - N/A
  - Disabled
  - N/A

- ON**
- Enabled
  - Enabled
  - N/A
  - Enabled
  - N/A

<b>Section [012]</b>	<b>Substation 4 Page Options</b>
<b>Options</b>	
[1]	Substation 4 can page Substation 1
[2]	Substation 4 can page Substation 2
[3]	Substation 4 can page Substation 3
[4] - [8]	Future Use

- OFF**
- Disabled
  - Disabled
  - Disabled
  - N/A

- ON**
- Enabled
  - Enabled
  - Enabled
  - N/A

**Section [013] Substation Panic Button Options**

<b>Options</b>	<b>Substation 1 Panic Button Options</b>			
		<b>[1]</b>	<b>[2]</b>	
	[1] & [2]	Disabled (default)	OFF	OFF
		Police panic	ON	OFF
		Medical panic	OFF	ON
	Fire panic	ON	ON	
<b>Options</b>	<b>Substation 2 Panic Button Options</b>			
		<b>[3]</b>	<b>[4]</b>	
	[3] & [4]	Disabled (default)	OFF	OFF
		Police panic	ON	OFF
		Medical panic	OFF	ON
	Fire panic	ON	OFF	
<b>Options</b>	<b>Substation 3 Panic Button Options</b>			
		<b>[5]</b>	<b>[6]</b>	
	[5] & [6]	Disabled (default)	OFF	OFF
		Police panic	ON	OFF
		Medical panic	OFF	ON
	Fire panic	ON	ON	
<b>Options</b>	<b>Substation 4 Panic Button Options</b>			
		<b>[7]</b>	<b>[8]</b>	
	[7] & [8]	Disabled (default)	OFF	OFF
		Police panic	ON	OFF
		Medical panic	OFF	ON
	Fire panic	ON	ON	

- OFF**
- see table
  - see table

- ON**
- see table
  - see table

- see table
- see table

- see table
- see table

- see table
- see table

- see table
- see table

- see table
- see table

- see table
- see table

<b>Section [014]</b>	<b>Substation Panic Audible Feedback</b>
<b>Options</b>	
[1]	Substation 1 Panic audible feedback
[2]	Substation 2 Panic audible feedback
[3]	Substation 3 Panic audible feedback
[4]	Substation 4 Panic audible feedback
[5] - [8]	Future Use

- OFF**
- Disabled
  - Disabled
  - Disabled
  - Disabled
  - N/A

- ON**
- Enabled
  - Enabled
  - Enabled
  - Enabled
  - N/A

<b>Section [015]</b>	<b>Audio Message Options 1</b>
<b>Options</b>	
[1]	Audio Message on Exit Delay
[2]	Audio Message on Arming
[3]	Audio Message on Disarming

- OFF**
- Disabled
  - Disabled
  - Disabled

- ON**
- Enabled
  - Enabled
  - Enabled



Section [015]	Audio Message Options 1		
[4]	Audio Message on Entry Delay	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> <b>Enabled</b>
[5]	Welcome Audio Message	<input checked="" type="checkbox"/> <b>Disabled</b>	<input type="checkbox"/> Enabled
[6]	Goodbye Audio Message	<input checked="" type="checkbox"/> <b>Disabled</b>	<input type="checkbox"/> Enabled
[7]	Audio Message on System Trouble	<input checked="" type="checkbox"/> <b>Disabled</b>	<input type="checkbox"/> Enabled
[8]	Installer In/Out Audio Message	<input checked="" type="checkbox"/> <b>Disabled</b>	<input type="checkbox"/> Enabled

Section [016]	Audio Message Options 2		
<b>Option</b>		<b>OFF</b>	<b>ON</b>
[1]	Music ON/OFF audio message	<input checked="" type="checkbox"/> <b>Disabled</b>	<input type="checkbox"/> Enabled
[2]	Personal recording ON/OFF audio message	<input checked="" type="checkbox"/> <b>Disabled</b>	<input type="checkbox"/> Enabled
[3]	Play "Armed" messages on Stay/Instant arming	<input checked="" type="checkbox"/> <b>Disabled</b>	<input type="checkbox"/> Enabled
[4]	Listen-In On/Off audio message	<input checked="" type="checkbox"/> <b>Disabled</b>	<input type="checkbox"/> Enabled
[5]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[6]	New alarm message (alarm in same partition)	<input type="checkbox"/> Beep	<input checked="" type="checkbox"/> <b>Voice</b>
[7]	New alarm report message (alarm in other partition)	<input type="checkbox"/> Beep	<input checked="" type="checkbox"/> <b>Voice</b>
[8]	To begin, enter account code message	<input type="checkbox"/> Beep	<input checked="" type="checkbox"/> <b>Voice</b>

Section [017]	Personalized Partition Audio Labels		
<b>Option</b>		<b>OFF</b>	<b>ON</b>
[1]	Partition 1's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[2]	Partition 2's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[3]	Partition 3's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[4]	Partition 4's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[5]	Partition 5's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[6]	Partition 6's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[7]	Partition 7's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[8]	Partition 8's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal

Section [018]	Personalized User Audio Labels		
<b>Option</b>		<b>OFF</b>	<b>ON</b>
[1]	Master's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[2]	User 2's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[3]	User 3's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[4]	User 4's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[5]	User 5's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[6]	User 6's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[7]	User 7's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[8]	User 8's audio label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal

Section [019]	Personalized Audio Labels		
<b>Option</b>		<b>OFF</b>	<b>ON</b>
[1]	System's Audio Label	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[2]	Alarm message	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[3]	Fire alarm message	<input checked="" type="checkbox"/> <b>Default</b>	<input type="checkbox"/> Personal
[4] - [8]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A

Section [020]	Substation 1 Partition Status		
<b>Option</b>		<b>OFF</b>	<b>ON</b>
[1]	Plays status of Partition 1	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> <b>Enabled</b>
[2]	Plays status of Partition 2	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> <b>Enabled</b>
[3]	Plays status of Partition 3	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> <b>Enabled</b>
[4]	Plays status of Partition 4	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> <b>Enabled</b>
[5]	Plays status of Partition 5	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> <b>Enabled</b>
[6]	Plays status of Partition 6	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> <b>Enabled</b>
[7]	Plays status of Partition 7	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> <b>Enabled</b>
[8]	Plays status of Partition 8	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> <b>Enabled</b>

**Section [021] Substation 2 Partition Status**

Option		OFF	ON
[1]	Plays status of Partition 1	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[2]	Plays status of Partition 2	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[3]	Plays status of Partition 3	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[4]	Plays status of Partition 4	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[5]	Plays status of Partition 5	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[6]	Plays status of Partition 6	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[7]	Plays status of Partition 7	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[8]	Plays status of Partition 8	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled

**Section [022] Substation 3 Partition Status**

Option		OFF	ON
[1]	Plays status of Partition 1	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[2]	Plays status of Partition 2	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[3]	Plays status of Partition 3	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[4]	Plays status of Partition 4	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[5]	Plays status of Partition 5	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[6]	Plays status of Partition 6	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[7]	Plays status of Partition 7	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[8]	Plays status of Partition 8	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled

**Section [023] Substation 4 Partition Status**

Option		OFF	ON
[1]	Plays status of Partition 1	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[2]	Plays status of Partition 2	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[3]	Plays status of Partition 3	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[4]	Plays status of Partition 4	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[5]	Plays status of Partition 5	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[6]	Plays status of Partition 6	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[7]	Plays status of Partition 7	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled
[8]	Plays status of Partition 8	<input type="checkbox"/> Disabled	<input checked="" type="checkbox"/> Enabled

Sections	Data	Description	Default
[024]	__/_/___ (005 to 255, 000 = All users, 001 = Master/User 1)	User Connection Access	001
[025]	__/_/___ (001 to 032 X 1 ring, 000 = disabled)	Ring Counter	006
[026]	__/_/___ (000 to 255 X 1 second, 000 = instant)	Answering Machine Override Delay	030
[027]	__/_/___ (000 to 255 X 1 second, 000 = instant)	TLM Fail Timer	030
[028]	__/_/___ (001 to 030 X 1 minute)	Call Back Connection Delay	005
[029]	__/_/___ Future Use	N/A	N/A
[030]	__/_/___ (005 to 255 X 1 second)	Connection Message Repeat Delay	030
[031]	__/_/___ (005 to 255 X 1 second)	Alarm Message Repeat Delay	020
[032]	__/_/___ (005 to 255 X 1 second)	Fire Alarm Message Repeat Delay	020
[033]	__/_/___ (010 to 060 X 1 second)	Response Connection Code Entry Delay	020
[034]	__/_/___ (020 to 060 X 1 second)	Call Back Connection Code Entry Delay	020
[035]	__/_/___ (005 to 115 X 1 second)	Pre-Alarm Audio Recording*	015
[036]	__/_/___ (005 to 115 X 1 second)	Post-Alarm Audio Recording*	015
[037]	__/_/___/___/___	Call Back Connection Access Code	000000

### Section [038] Substation 1 Mute Schedule

Start Time	End Time	Days (Turn ON or OFF)
Schedule A: ____ : ____	____ : ____	<b>S M T W T F S H</b> 1 2 3 4 5 6 7 8
Schedule B: ____ : ____	____ : ____	1 2 3 4 5 6 7 8

### Section [039] Substation 2 Mute Schedule

Start Time	End Time	Days (Turn ON or OFF)
Schedule A: ____ : ____	____ : ____	<b>S M T W T F S H</b> 1 2 3 4 5 6 7 8
Schedule B: ____ : ____	____ : ____	1 2 3 4 5 6 7 8

### Section [040] Substation 3 Mute Schedule

Start Time	End Time	Days (Turn ON or OFF)
Schedule A: ____ : ____	____ : ____	<b>S M T W T F S H</b> 1 2 3 4 5 6 7 8
Schedule B: ____ : ____	____ : ____	1 2 3 4 5 6 7 8

### Section [041] Substation 4 Mute Schedule

Start Time	End Time	Days (Turn ON or OFF)
Schedule A: ____ : ____	____ : ____	<b>S M T W T F S H</b> 1 2 3 4 5 6 7 8
Schedule B: ____ : ____	____ : ____	1 2 3 4 5 6 7 8


## Using the Memory Key

**[100]** Download programming from the Memory Key to the Listen-In Module.

**[110]** Copy programming from the Listen-In Module to the Memory Key


### Download Contents of the Memory Key to the Listen-In Module

- 1) Insert the Memory Key onto the Listen-In module's connector labelled "KEY".
- 2) To download the contents of the Memory Key, enter the Listen-In Module's programming mode and enter section **[100]**.
- 3) Once the keypad emits a confirmation beep, wait for a second confirmation beep and then remove the Memory Key.




### Copy Contents of the Listen-In Module to the Memory Key

- 1) Insert Memory Key onto the Listen-In module's connector labelled "KEY". Ensure that the 'write protect' jumper is on (refer to *Memory Key* below).
- 2) To copy the contents to the Memory Key, enter the Listen-In module's programming mode and enter section **[110]**.
- 3) Once the Listen-In module emits a confirmation beep, wait for a second confirmation beep and then remove the Memory Key. Remove the Memory Key's jumper if you do not wish to accidentally overwrite its contents.



## Memory Key



## Combus Voltmeter

To verify if the combus is supplying sufficient power, enter the Listen-in module programming mode and enter section **[050]**. A reading of 12V or lower indicates that the voltage is too low. The voltage may drop during the control panel or external power supply battery test. Press **[ENTER]** to refresh the display.

# DGP-ACM12

## 4-Wire Access Control Module



△ = Default setting

### Section [001] Partition Assignment

#### Option

- [1] *Partition 1*
- [2] *Partition 2*
- [3] *Partition 3*
- [4] *Partition 4*
- [5] *Partition 5 (EVO 192 only)*
- [6] *Partition 6 (EVO 192 only)*
- [7] *Partition 7 (EVO 192 only)*
- [8] *Partition 8 (EVO 192 only)*

#### OFF

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

#### ON

- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled
- △ Enabled

### Section [002] General Options 1

#### Option

- [1] *Tamper Input*
- [2] *Battery Charging Current*
- [3] *Reader's red LED to follow partition's status*
- [4] *Reader's beeping to follow partition's status when option [3] is ON*
- [5] *Card activates door unlocked schedule*
- [6] *Door will relock*
- [7] *Reader's green LED for Access Granted*
- [8] *Unlock on Request for Exit (REX)*

#### OFF

- △ Disabled
- △ 350mA
- Disabled
- Disabled
- Disabled
- △ Immediately
- Disabled
- Disabled

#### ON

- Enabled
- 800mA
- △ Enabled
- △ Enabled
- △ Enabled
- When closed
- △ Enabled
- △ Enabled

### Section [003] General Options 2

#### Option

- [1] *Door Left Open Alarm*
- [2] *Door Left Open Pre-alarm*
- [3] *Door Left Open Alarm*
- [4] *Door Left Open Alarm follows*
- [5] *Door Forced Open Alarm*
- [6] *Door Forced Alarm*
- [7] *Door Forced Alarm follows*
- [8] *Reader Access Feedback*

#### OFF

- △ Disabled
- Disabled
- Silent
- △ Alarm Restore
- △ Disabled
- Silent
- △ Alarm Restore
- Visual

#### ON

- Enabled
- △ Enabled
- △ Audible
- Beep Timer
- Enabled
- △ Audible
- Beep Timer
- △ Visual and Audible

<b>Section [004]</b>	<b>PGM Options</b>
<b>Options</b>	
[1]	<i>PGM Deactivation After</i>
[2]	<i>PGM Normal State</i>
[3]	<i>PGM Base Time</i>
[4] & [5]	<i>Special</i>
[6]	<i>Reader Locate Feedback</i>
[7]	<i>Unlock Door on Fire Alarm</i>
[8]	<i>AC and Battery Supervision</i>

	[4]	[5]
<input type="checkbox"/> Card Only	OFF	OFF
<input type="checkbox"/> PIN Only	ON	OFF
<input type="checkbox"/> Card and PIN	OFF	ON
△ Card or PIN	ON	ON

- OFF**
- △ Deactivation Event
  - △ N.O.
  - △ 1 second
- ON**
- PGM Timer
  - N.C.
  - 1 minute

- see table
- see table

- △ Visual
- △ Disabled
- △ Enabled
- Visual & audible
- Enabled
- Disabled


Section	Data	Description	Default
[005]	__/__/__ (000 to 255 x 1 minute; 000 = Instant)	AC failure report delay	030
[006]	__/__/__ (001 to 255 seconds)	Door Unlocked Period	005
[007]	__/__/__ (001 to 255 seconds added to section [006])	Door Unlocked Period extension	015
[008]	__/__/__ (001 to 255 seconds)	Door Left Open Interval	060
[009]	__/__/__ (001 to 255 seconds) Time to start pre-alarm before alarm is triggered	Door Left Open Pre-Alarm Timer	015
[010]	__/__/__ (001 to 255 seconds)	Beep timer for Door Left Open Alarm	005
[011]	__/__/__ (001 to 255 seconds)	Beep timer for Door Forced Open alarm	005
[012]	__/__/__ (000 to 255; refer to option [3] in section [004])	PGM timer	005

**Section [013] Door Unlocked Schedule**

Start Time	End Time	Days (Turn ON or OFF)
		S M T W T F S H
Schedule A: ____ : ____	____ : ____	1 2 3 4 5 6 7 8
Schedule B: ____ : ____	____ : ____	1 2 3 4 5 6 7 8

<b>Sections</b>	<b>PGM Activation Event</b>
[014]	__/__/__ Event Group
[015]	__/__/__ Feature Group
[016]	__/__/__ Start #
[017]	__/__/__ End #

<b>Sections</b>	<b>PGM Deactivation Event</b>
[018]	__/__/__ Event Group
[019]	__/__/__ Feature Group
[020]	__/__/__ Start #
[021]	__/__/__ End #

 Only Event Groups 000 to 055, 062 and 063 can be used to program the module's PGM.

**Section [022] Safe Mode Options**

**Option**

- [1] *Safe Mode*
- [2] *Safe Mode Access*
- [3] *Reader Safe Mode Feedback*
- [4] *Unlock Door in Safe Mode*
- [5] *Access Cards in Safe Mode*
- [6] to [8] *Future Use*

**OFF**

- Disabled
- Disabled
- Visual**
- Disabled**
- Safe Cards only**
- N/A

**ON**

- Enabled**
- Enabled**
- Visual & audible
- Enabled
- Any Cards
- N/A

Section	Data	Description	Default
[023]	__/__/__ (001 to 024 hours; 000 = Disabled)	Safe Mode Door Unlocked Period	000
[024]	__/__/__ (001 to 255 seconds; 000 = Follow REX)	REX Unlocked Period	000
[025]	__/__/__ (000 to 003)	Red LED Brightness	002
[026]	__/__/__ (000 to 003)	Green LED Brightness	002
[027]	__/__/__ (000 to 003)	Buzzer Frequency	001
[028]	__/__/__ (000 to 255 minutes; 000 = instant)	AC Restore Report Delay	005
[029]	__/__/__ (000 to 255 minutes)	Stay Lock Delay	000
[030]	<b>Test PGM:</b> Activates the PGM for 8 seconds to verify if the PGM is functioning properly.		

**Section [031] Safe Mode Options**

**Option**

- [1] *Flexible PGM Deactivation Option*
- [2] *Reload Timer on Activation Event*
- [3] to [8] *Future Use*

**OFF**

- Disabled
- Disabled
- N/A

**ON**

- Enabled**
- Enabled**
- N/A

Section	Description
[070]	Delete All Safe Mode Access Cards
[071]	Delete Safe Mode Access Card 1
[072]	Delete Safe Mode Access Card 2
[073]	Delete Safe Mode Access Card 3
[074]	Delete Safe Mode Access Card 4



*The DGP-ACM12 has a build-in supervised 1.5A switching power supply and needs to be connected to a transformer.*

# APR3-PGM4 V2.0

## 4-PGM Expansion Module



△ = Default setting

Section[001]	General Options	OFF	ON
Option			
[1]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[2]	Pulse Output for Fire Alarms	△ Disabled	<input type="checkbox"/> Enabled
[3]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[4]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[5]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[6]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[7]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[8]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A

Section [002]	PGM Options	OFF	ON
Option			
[1]	PGM1 Deactivation After	△ Deactivation Event	<input type="checkbox"/> PGM Timer
[2]	PGM1 Base Time	△ 1 second	<input type="checkbox"/> 1 minute
[3]	PGM2 Deactivation After	△ Deactivation Event	<input type="checkbox"/> PGM Timer
[4]	PGM2 Base Time	△ 1 second	<input type="checkbox"/> 1 minute
[5]	PGM3 Deactivation After	△ Deactivation Event	<input type="checkbox"/> PGM Timer
[6]	PGM3 Base Time	△ 1 second	<input type="checkbox"/> 1 minute
[7]	PGM4 Deactivation After	△ Deactivation Event	<input type="checkbox"/> PGM Timer
[8]	PGM4 Base Time	△ 1 second	<input type="checkbox"/> 1 minute

Section	Data	Description	Default
[003]	__/__/__ (000 to 255; see option [2] in section [002])	PGM1 Timer	005
[012]	__/__/__ (000 to 255; see option [4] in section [002])	PGM2 Timer	005
[021]	__/__/__ (000 to 255; see option [6] in section [002])	PGM3 Timer	005
[030]	__/__/__ (000 to 255; see option [8] in section [002])	PGM4 Timer	005

		Event Group		Feature Group		Start #		End #	
		Section		Section		Section		Section	
PGM Activation	PGM1	[004]	__/__/__	[005]	__/__/__	[006]	__/__/__	[007]	__/__/__
	PGM2	[013]	__/__/__	[014]	__/__/__	[015]	__/__/__	[016]	__/__/__
	PGM3	[022]	__/__/__	[023]	__/__/__	[024]	__/__/__	[025]	__/__/__
	PGM4	[031]	__/__/__	[032]	__/__/__	[033]	__/__/__	[034]	__/__/__
PGM Deactivation	PGM1	[008]	__/__/__	[009]	__/__/__	[010]	__/__/__	[011]	__/__/__
	PGM2	[017]	__/__/__	[018]	__/__/__	[019]	__/__/__	[020]	__/__/__
	PGM3	[026]	__/__/__	[027]	__/__/__	[028]	__/__/__	[029]	__/__/__
	PGM4	[035]	__/__/__	[036]	__/__/__	[037]	__/__/__	[038]	__/__/__

 Refer to Appendix 1: Programming PGMs on page 52 for the PGM Table. All the Event Groups can be used to program the module's PGM(s).

# APR3-ADM2 V2.0

## Voice Assisted Arm/Disarm Module



Section	Data	Description	Default
[001]	__/_/__(000 to 255; Number of rings)	Ring counter	8 rings
[002]	__/_/__(000 to 255 seconds)	Answering machine override	Disabled
[003]	__/_/__(000 to 255; refer to option [4] in section [004])	PGM timer	005
(000 = follows manual activation/deactivation of PGM by first pressing [#] and then [0])			
△ = Default setting			
<b>Section [004]</b>	<b>General Options</b>		
<b>Option</b>		<b>OFF</b>	<b>ON</b>
[1]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[2]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[3]	PGM Output	△ Disabled	<input type="checkbox"/> Enabled
[4]	PGM Base Time	△ Seconds	<input type="checkbox"/> Minutes
[5]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[6]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[7]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
[8]	Future Use	<input type="checkbox"/> N/A	<input type="checkbox"/> N/A
<b>Section [005]</b>	<b>Partition Assignment</b>		
<b>Option</b>		<b>OFF</b>	<b>ON</b>
[1]	Partition 1	<input type="checkbox"/> Disabled	△ Enabled
[2]	Partition 2	<input type="checkbox"/> Disabled	△ Enabled
[3]	Partition 3	<input type="checkbox"/> Disabled	△ Enabled
[4]	Partition 4	<input type="checkbox"/> Disabled	△ Enabled
[5]	Partition 5 (EVO192 only)	<input type="checkbox"/> Disabled	△ Enabled
[6]	Partition 6 (EVO192 only)	<input type="checkbox"/> Disabled	△ Enabled
[7]	Partition 7 (EVO192 only)	<input type="checkbox"/> Disabled	△ Enabled
[8]	Partition 8 (EVO192 only)	<input type="checkbox"/> Disabled	△ Enabled



# APR-PRT3 V1.0

## Integration Module



△ = Default setting

### Section [001] Partition Assignment

#### Option

- [1] *Partition 1*
- [2] *Partition 2*
- [3] *Partition 3*
- [4] *Partition 4*
- [5] *Partition 5 (EVO192 only)*
- [6] *Partition 6 (EVO192 only)*
- [7] *Partition 7 (EVO192 only)*
- [8] *Partition 8 (EVO192 only)*

#### OFF

- Disabled
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**

#### ON

- △ **Enabled**
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

### Section [002] Automatic Printing of Zone Status (1 to 8)

#### Option

- [1] *Print Status of Zone 1*
- [2] *Print Status of Zone 2*
- [3] *Print Status of Zone 3*
- [4] *Print Status of Zone 4*
- [5] *Print Status of Zone 5*
- [6] *Print Status of Zone 6*
- [7] *Print Status of Zone 7*
- [8] *Print Status of Zone 8*

#### OFF

- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**

#### ON

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

### Section [003] Automatic Printing of Zone Status (9 to 16)

#### Option

- [1] *Print Status of Zone 9*
- [2] *Print Status of Zone 10*
- [3] *Print Status of Zone 11*
- [4] *Print Status of Zone 12*
- [5] *Print Status of Zone 13*
- [6] *Print Status of Zone 14*
- [7] *Print Status of Zone 15*
- [8] *Print Status of Zone 16*

#### OFF

- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**

#### ON

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

### Section [004] Automatic Printing of Zone Status (17 to 24)

#### Option

- [1] *Print Status of Zone 17*
- [2] *Print Status of Zone 18*
- [3] *Print Status of Zone 19*
- [4] *Print Status of Zone 20*
- [5] *Print Status of Zone 21*
- [6] *Print Status of Zone 22*
- [7] *Print Status of Zone 23*
- [8] *Print Status of Zone 24*

#### OFF

- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**
- △ **Disabled**

#### ON

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

**Section [005] Automatic Printing of Zone Status (25 to 32)**

**Option**

- [1] *Print Status of Zone 25*
- [2] *Print Status of Zone 26*
- [3] *Print Status of Zone 27*
- [4] *Print Status of Zone 28*
- [5] *Print Status of Zone 29*
- [6] *Print Status of Zone 30*
- [7] *Print Status of Zone 31*
- [8] *Print Status of Zone 32*

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

**ON**

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

**Section [006] Automatic Printing of Zone Status (33 to 40)**

**Option**

- [1] *Print Status of Zone 33*
- [2] *Print Status of Zone 34*
- [3] *Print Status of Zone 35*
- [4] *Print Status of Zone 36*
- [5] *Print Status of Zone 37*
- [6] *Print Status of Zone 38*
- [7] *Print Status of Zone 39*
- [8] *Print Status of Zone 40*

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

**ON**

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

**Section [007] Automatic Printing of Zone Status (41 to 48)**

**Option**

- [1] *Print Status of Zone 41*
- [2] *Print Status of Zone 42*
- [3] *Print Status of Zone 43*
- [4] *Print Status of Zone 44*
- [5] *Print Status of Zone 45*
- [6] *Print Status of Zone 46*
- [7] *Print Status of Zone 47*
- [8] *Print Status of Zone 48*

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

**ON**

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

**Section [008] Automatic Printing of Zone Status (49 to 56)**

**Option**

- [1] *Print Status of Zone 49 (EVO192 only)*
- [2] *Print Status of Zone 50 (EVO192 only)*
- [3] *Print Status of Zone 51 (EVO192 only)*
- [4] *Print Status of Zone 52 (EVO192 only)*
- [5] *Print Status of Zone 53 (EVO192 only)*
- [6] *Print Status of Zone 54 (EVO192 only)*
- [7] *Print Status of Zone 55 (EVO192 only)*
- [8] *Print Status of Zone 56 (EVO192 only)*

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

**ON**

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

**Section [009] Automatic Printing of Zone Status (57 to 64)**

**Option**

- [1] *Print Status of Zone 57 (EVO192 only)*
- [2] *Print Status of Zone 58 (EVO192 only)*
- [3] *Print Status of Zone 59 (EVO192 only)*
- [4] *Print Status of Zone 60 (EVO192 only)*
- [5] *Print Status of Zone 61 (EVO192 only)*
- [6] *Print Status of Zone 62 (EVO192 only)*
- [7] *Print Status of Zone 63 (EVO192 only)*
- [8] *Print Status of Zone 64 (EVO192 only)*

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

**ON**

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

**Section [010] Automatic Printing of Zone Status (65 to 72)**

**Option**

- [1] *Print Status of Zone 65 (EVO192 only)*
- [2] *Print Status of Zone 66 (EVO192 only)*
- [3] *Print Status of Zone 67 (EVO192 only)*
- [4] *Print Status of Zone 68 (EVO192 only)*
- [5] *Print Status of Zone 69 (EVO192 only)*
- [6] *Print Status of Zone 70 (EVO192 only)*
- [7] *Print Status of Zone 71 (EVO192 only)*
- [8] *Print Status of Zone 72 (EVO192 only)*

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

**ON**

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

**Section [011] Automatic Printing of Zone Status (73 to 80)**

**Option**

- [1] *Print Status of Zone 73 (EVO192 only)*
- [2] *Print Status of Zone 74 (EVO192 only)*
- [3] *Print Status of Zone 75 (EVO192 only)*
- [4] *Print Status of Zone 76 (EVO192 only)*
- [5] *Print Status of Zone 77 (EVO192 only)*
- [6] *Print Status of Zone 78 (EVO192 only)*
- [7] *Print Status of Zone 79 (EVO192 only)*
- [8] *Print Status of Zone 80 (EVO192 only)*

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

**ON**

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

**Section [012] Automatic Printing of Zone Status (81 to 88)**

**Option**

- [1] *Print Status of Zone 81 (EVO192 only)*
- [2] *Print Status of Zone 82 (EVO192 only)*
- [3] *Print Status of Zone 83 (EVO192 only)*
- [4] *Print Status of Zone 84 (EVO192 only)*
- [5] *Print Status of Zone 85 (EVO192 only)*
- [6] *Print Status of Zone 86 (EVO192 only)*
- [7] *Print Status of Zone 87 (EVO192 only)*
- [8] *Print Status of Zone 88 (EVO192 only)*

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

**ON**

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

**Section [013] Automatic Printing of Zone Status (89 to 96)**

**Option**

- [1] *Print Status of Zone 89 (EVO192 only)*
- [2] *Print Status of Zone 90 (EVO192 only)*
- [3] *Print Status of Zone 91 (EVO 192 only)*
- [4] *Print Status of Zone 92 (EVO 192 only)*
- [5] *Print Status of Zone 93 (EVO192 only)*
- [6] *Print Status of Zone 94 (EVO192 only)*
- [7] *Print Status of Zone 95 (EVO192 only)*
- [8] *Print Status of Zone 96 (EVO192 only)*

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

**ON**

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

**Section [014] Automatic Printing of Event Groups**

**Option**

- [1] *Print Miscellaneous Events*
- [2] *Print Arming/Disarming Events*
- [3] *Print Alarm/Alarm Restore Events*
- [4] *Print Tamper/Tamper Restore Events*
- [5] *Print Troubles/Troubles Restore Events*
- [6] *Print Special Events*
- [7] *Print Access Events*
- [8] *Future Use*

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- N/A

**ON**

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- N/A

**Section [015] Printer Setup Options**

**Option**

- [1] *Parallel Port*
- [2] *Future Use*
- [3] *Off-line Status Ignored*
- [4] *Paper Empty Status Ignored*
- [5] *Printer Fault Status Ignored*
- [6] *Printer Busy Status Ignored*
- [7] *Future Use*
- [8] *Future Use*

**OFF**

- Disabled**
- N/A
- Disabled**
- Disabled**
- Disabled**
- Disabled**
- N/A
- N/A

**ON**

- Enabled
- N/A
- Enabled
- Enabled
- Enabled
- Enabled
- N/A
- N/A

**Section [016] Serial Port Setup Options**

**Option**

[1] *Serial Port*

[2] & [3]

Baud Rate Settings	
[2]	[3]
OFF	OFF — 2400 Baud
ON	OFF — 9600 Baud
OFF	ON — 19200 Baud
ON	ON — 57600 Baud

[4] to [8]

*Future Use*

**OFF**

- Disabled**
- See Table
- See Table

**ON**

- Enabled
- See Table
- See Table

N/A

N/A

**Section [017] PGM Options**

**Option**

- [1] *PGM Deactivation After*
- [2] *PGM Normal State*
- [3] *PGM Base Time*
- [4] *Future Use*
- [5] *Tamper Recognition*
- [6] to [8] *Future Use*

**OFF**

- Deactivation Event**
- N.O.**
- 1 second**
- N/A
- Disabled**
- N/A

**ON**

- PGM Timer
- N.C.
- 1 minute
- N/A
- Enabled
- N/A

**Section**

**Data**

[018] *\_\_/\_\_/\_\_* (000 to 255; see option [3] in section [017])

**Description**

PGM Timer

**Default**

005

**Sections**

**PGM Activation Event**

- [019] *\_\_/\_\_/\_\_* Event Group
- [020] *\_\_/\_\_/\_\_* Feature Group
- [021] *\_\_/\_\_/\_\_* Start #
- [022] *\_\_/\_\_/\_\_* End #

**Sections**

**PGM Deactivation Event**

- [023] *\_\_/\_\_/\_\_* Event Group
- [024] *\_\_/\_\_/\_\_* Feature Group
- [025] *\_\_/\_\_/\_\_* Start #
- [026] *\_\_/\_\_/\_\_* End #



Refer to Appendix 1: Programming PGMs on page 52 for the PGM Table. Only Event Groups 000 to 055 can be used to program the module's PGM.

## Manual Printing Programming

Section	Data	Description	Default
[027]	__/_/__(000 to 255)**	Miscellaneous Events	(Event Group Selection) 000
[028]	__/_/__(000 to 255)**		(Feature Group Selection) 000
[029]	__/_/__(000 to 255)**		(Event Start # Selection) 000
[030]	__/_/__(000 to 255)**		(Event End # Selection) 000
[031]	__/_/__(000 to 255)**	Arming/Disarming Events	(Event Group Selection) 000
[032]	__/_/__(000 to 255)**		(Feature Group Selection) 000
[033]	__/_/__(000 to 255)**		(Event Start # Selection) 000
[034]	__/_/__(000 to 255)**		(Event End # Selection) 000
[035]	__/_/__(000 to 255)**	Alarm/Alarm Restore Events	(Event Group Selection) 000
[036]	__/_/__(000 to 255)**		(Feature Group Selection) 000
[037]	__/_/__(000 to 255)**		(Event Start # Selection) 000
[038]	__/_/__(000 to 255)**		(Event End # Selection) 000
[039]	__/_/__(000 to 255)**	Tamper/Tamper Restore Events	(Event Group Selection) 000
[040]	__/_/__(000 to 255)**		(Feature Group Selection) 000
[041]	__/_/__(000 to 255)**		(Event Start # Selection) 000
[042]	__/_/__(000 to 255)**		(Event End # Selection) 000
[043]	__/_/__(000 to 255)**	Trouble/Trouble Restore Events	(Event Group Selection) 000
[044]	__/_/__(000 to 255)**		(Feature Group Selection) 000
[045]	__/_/__(000 to 255)**		(Event Start # Selection) 000
[046]	__/_/__(000 to 255)**		(Event End # Selection) 000
[047]	__/_/__(000 to 255)**	Special Events	(Event Group Selection) 000
[048]	__/_/__(000 to 255)**		(Feature Group Selection) 000
[049]	__/_/__(000 to 255)**		(Event Start # Selection) 000
[050]	__/_/__(000 to 255)**		(Event End # Selection) 000
[051]	__/_/__(000 to 255)**	Access Events	(Event Group Selection) 000
[052]	__/_/__(000 to 255)**		(Feature Group Selection) 000
[053]	__/_/__(000 to 255)**		(Event Start # Selection) 000
[054]	__/_/__(000 to 255)**		(Event End # Selection) 000
[055]	__/_/__(000 to 255)**	All Events	(Event Group Selection) 000
[056]	__/_/__(000 to 255)**		(Feature Group Selection) 000
[057]	__/_/__(000 to 255)**		(Event Start # Selection) 000
[058]	__/_/__(000 to 255)**		(Event End # Selection) 000
<b>Section</b>	<b>Description</b>		
[060]	<b>Test PGM:</b> Activates the PGM for 8 seconds to verify if the PGM is functioning properly.		



# DGP2-PS17 V1.0

## Power Supply

△ Default Setting

### Section [001] General Options

#### Option

- [1] PGM Tamper Recognition
- [2] Battery Charging Current
- [3] PGM Deactivation After
- [4] PGM Base Time
- [5] to [8] Future Use

#### OFF

- △ PGM Tamper Recognition
- △ Battery Charging Current
- △ Deactivation Event
- △ 1 second
- N/A

#### ON

- Tamper report sent to the panel
- Charging current at 850mA
- PGM Timer
- 1 minute
- N/A



A 40VA transformer is required when selecting the 850mA battery charge current. Using a 20VA transformer with a battery charge current of 850mA may damage the system.

#### Sections

#### Data

#### Description

#### Default

- |       |  |                         |     |
|-------|--|-------------------------|-----|
| [002] | _/_/_ (001 to 255 X 1 minute, 000 = instant)   | AC Failure Report Delay | n/a |
| [003] | _/_/_ (000 to 255; refer to option [4] in section [001])<br>Option [8] must be enabled before the PGM modes can be tested. | PGM Timer               | n/a |

#### Sections

#### PGM Activation Event

- [004] \_/\_/\_ Event Group
- [005] \_/\_/\_ Feature Group
- [006] \_/\_/\_ Start #
- [007] \_/\_/\_ End #

#### Sections

#### PGM Deactivation Event

- [008] \_/\_/\_ Event Group
- [009] \_/\_/\_ Feature Group
- [010] \_/\_/\_ Start #
- [011] \_/\_/\_ End #



Refer to Appendix 1: Programming PGMs on page 52 for the PGM Table. Only Event Groups 000 to 055 can be used to program the module's PGM.


#### Section

#### Description

- [020] Test PGM: Activates the PGM for 8 seconds to verify if the PGM is functioning properly.


# Module Connection Drawings

**Figure 1: Connecting the Combus**




**Figure 2: Connecting a 5A PGM Output**

Some modules' PGM output(s) are comprised of one or more 5A relays. Connect the PGM output as shown below. For the external power supply, we recommend the DGP2-PS17 Power Supply Module.



**Figure 3: Connecting a 50mA PGM Output**

Some modules' PGM output is comprised of one 50mA output. Connect the PGM output as shown below.



## Module LED Indications

Green **LOCATE** LED (sometimes seen as **LOC** or **LC**):

*Power Up:* Remains illuminated during power up.

*Locate:* If the LED flashes fast during normal operation, it is receiving a "locate" request from the control panel. Depending on the module, the "locate" request can be disabled by pressing on the tamper switch or on the "Disable Locate" switch.

Red **WATCHDOG** LED (sometimes seen as **WDG**, **WTDG** or **WD**):

*Status:* Flashes to indicate proper operation.

Communication Failure:

If both the **LOCATE** and **WATCHDOG** LEDs are alternately flashing, the module is experiencing a communication failure with the control panel.

Green **BATT** LED (DGP2-ACM1P and DGP2-PS17 only):

Charging and battery test LED (every 60 seconds).

Green **RX** LED (MG-RTX3 only):

*Flashing:* The printer module is transmitting data through the serial port.

Green **PULSE** LED (APR-ADM2 only):

Will illuminate whenever the APR3-ADM2 is using its dialer. The **PULSE** LED will remain illuminated for the whole duration that the dialer is being used.







**Remove AC and battery power from the control panel before connecting the module to the combus.**




**Refer to the appropriate control panel's Reference & Installation Manual for the maximum allowable installation distance from the control panel.**

# Grafica Graphic LCD Keypad Module (DNE-K07)







## LCD Keypad Module (EVO641/EVO641R)



## 48-Zone LED Keypad Module (DGP2-648)




## EVO641/EVO641R Access Control Connections



## Annunciator Module (DGP2-ANC1B)

Figure 1: Cut-out Spaces




Use a knife to cut away two holes approximately 75mm from the Annunciator's back plate. Cut a square in front of the guide clip (A) and at the top of the rim (B). Dotted lines indicate cutting lines.




Remove **B** from any Annunciator that will have additional modules stacked on top of it as shown in Figure 3 (below). Uppermost Annunciators such as module 3 in Figure 3 or stand-alone modules do not require the removal of **B**.

Figure 2: Mounting



Remove the plastic square from keypad's top back plate E.

Figure 3: Stacking






Connect wires to keypad or combus terminals.



Connect wires using **A**, **B** and the guide clip on the Annunciator's back plate as shown in Figure 1 (above).

When the control panel's locate function is enabled, the first row of green LEDs will flash.

## Outdoor High-Security Digital Motion Detector Module (DG85)




### PCB HEIGHT ADJUSTMENT

The DG85 is designed for optimal performance at a height of 2.1m (7ft), but can be installed lower or higher. After you have installed the detector, ensure that the PCB Height Markings match the installation height. The installation height is measured from the ground to the base of DG85's cover. For example, if the motion detector is installed at a height of 2.1m (7ft), the PCB should then be adjusted to 2.1m (7ft). To adjust the PCB height, remove the PCB screw and align the PCB Height Tab with the desired height marking on the PCB.


**WARNING:** Ensure that the unit's front and back cover are tightly joined together, without any spacing around the rim of the unit, before tightening the screw. Otherwise the weatherproof casing may be compromised and moisture may enter the unit.

# Motion Detector Modules (DGP2-50/60/70)



## Addressable Digital Motion Detectors (DGP2-50/60)



## Addressable High-Security Motion Detectors (DGP2-70)



- 1) LENS
- 2) BEZEL PIN
- 3) SENSOR (S)
- 4) ANTI-TAMPER SWITCH
- 5) PCB SCREWS
- 6) METAL SHIELD
- 7) DETECT/ALARM LED (red)  
*Flashing:* Unable to communicate with the control panel.
- 8) PROTECT INDICATOR LED (green)  
*Locate:* If activated, the LED will flash until the Anti-Tamper Switch is pressed or the detector's serial number is entered
- 9) PCB HEIGHT TAB






### PCB Height Adjustment

DGP2-50/60/70 is designed for optimal performance at a height of 2.1m (7ft), but can be installed lower or higher. After you have installed the motion detector, ensure that the PCB Height Markings match the installation height. The installation height is measured from the ground to the base of the motion detector's cover.

For example, if the motion detector is installed at a height of 2.1m (7ft), the PCB should then be adjusted to 2.1m (7ft). To adjust the PCB height, remove the PCB screw and align the PCB Height Tab with the desired height marking on the PCB.

### PCB Height Markings




## Magellan Wireless Expansion Module (MG-RTX3)

- ERROR (Red): Indicates a problem with the module.
- BUS RX (Green): Flashes when receiving information from the panel.
- BUS TX (Red): Flashes when transmitting information to the panel.
- RF RX (Green): Flashes when receiving wireless information.
- RF TX (Yellow): Flashes when transmitting wireless information.

Connect to a 307USB and use WinLoad's In-Field Firmware Upgrade Application to upgrade the firmware


Anti-Tamper Switch



Refer to PGM Connection for connection information.

Refer to Module Connection Drawings on page 39 for information.

**System Reset:** Press and hold the Programming button for 5 seconds, the BUS RX LED will flash. Release the button and press it again while the LED flashes to reset the module to its default values. This is only possible in the first 30 seconds after the MG-RTX3 is powered up.




Use a relay if the current draw will exceed 150mA.


Connect to an external Power Supply (PS-17 recommended)

Connect to any device such as a garage door, light or siren.

## Digital Ceiling Mounted Motion Detector Module (DG467)




## 4-PGM Expansion Module (APR3-PGM4)



Refer to Module Connection drawings on page 39 for information.

## 8-Zone Expansion Module (APR-ZX8)

Input terminal Z8 can be used as an anti-tamper switch input Option [1]: Section [001]




Open Collector (Negative Trigger) 12 Vdc 50 mA To drive more than 50mA use a 12Vdc relay

Refer to Module Connection drawings on page 39 for information.

## 4-zone Expansion Module (APR3-ZX4)


A "Locate" request coming from the control panel can be disabled by pressing the "Disable Locate" switch.



Connect the detection devices to the APR3-ZX4 input terminals exactly as shown in the control panel *Programming Guide*.

Refer to Module Connection Drawings on page 39 for information.


For information on the 4-zone Hardwire Module's LEDs, refer to Module LED Indications on page 39.



## One-zone Expansion Module (DGP2-ZX1)

N.C., With EOL


Refer to the appropriate control panel Reference & Installation Manual for additional configurations. The DGP2-ZX1 follows the ATZ and EOL definitions set in the control panel.




Anti-Tamper Switch  
Pressing the anti-tamper switch can also be used to disengage "Locate".

Refer to Module Connection Drawings on page 39 for information.

## Listen-in Modules (DGP-LSN4 & DGP-SUB1)




## InTouch Voice-Assisted Arm/Disarm Module (APR3-ADM2)



Refer to Module Connection drawings on page 39 for information.

## Integration module (APR-PRT3)

For information on the Printer Module's LEDs, refer to Module LED Indications on page 39.




Refer to Module Connection Drawings on page 39 for information.

- 1) LED feedback
- 2) 25-Pin Parallel Port: Connect the Printer Module's 25-pin parallel port to any dot matrix printer.  
Note: The dot matrix printer must support a minimum of 80 columns.
- 3) 9-Pin Serial Port: Connect the Printer Module's 9-Pin serial port to a dot matrix printer.  
Note: The dot matrix printer must support a minimum of 80 columns.
- 4) 9-pin Serial Port: Connect the Printer Module's 9-pin serial port to a home automation module.
- 5) 9-pin Serial Port: Connect C-Bus to the Printer Module using a **null modem cable**.
- 6) 9-pin Serial Port: Connect either the Printer Module's USB or 9-pin serial port to a computer's COM port to view the control panel's events on the computer's monitor. The events display on the monitor can then be printed through the printer connected to the computer.

# Access Control Module (DGP-ACM12)









**Caution:**  
Disconnect battery before replacing fuse.



**Rechargeable Battery**  
YUASA model #NP7-12 UL/ULC  
12Vdc/4Ah




**When using the on-board power supply, the 12Vdc power supply output will automatically shut down if the current exceeds 1.1A (see Inset 1).**






# Power Supply Module (DGP2-PS17)



For information on the Power Supply Module's LEDs, refer to Module LED Indications on page 39.

**Caution:**  
Disconnect battery before replacing the fuse.

http://www.paradox.ca



Control Panel (EVO48 & EVO192)

**Warning:** Improper connection of the transformer may result in damage to the system.

**Warning:** The 12Vdc power supply output will automatically shut down if the current exceeds 1.1A.



**Warning:** A 40VA transformer is required when selecting the 850mA battery charge current. Using a 20VA transformer with a battery charge current of 850mA may damage the system.

<b>Transformer Requirements:</b>	Minimum:	UL/C-UL:
UL Listed Basler Electronics Transformers	16VAC 20VA	16VAC 40VA
CSA Listed Basler Electronics Transformers		#BE156240CAA
		#BE116240AAA
<b>Auxiliary Supply can provide:</b>	typical 600mA	typical 600mA
	max. 700mA	max. 700mA
<b>Usable Battery Charge Currents:</b>	350mA	350mA/850mA


Refer to Module Connection Drawings on page 39 for information on how to connect the Power Supply Module's PGM output (Figure 2). Before commencing with the connections, please read the General Warnings listed on page 40.

# Door Contact Module (DGP2-ZC1)

For information on the Addressable Door Contact's LEDs, refer to Module LED Indications on page 39.




# Hub and Bus Isolator Module (APR3-HUB2)



The APR3-HUB2 is non-addressable, therefore you can connect an unlimited amount of hubs to the combus without affecting the total number of modules supported by the control panel.

## VDMP3 Plug-in Voice Dialer



*For programming method, refer to panel programming guide.*

# Appendix 1: Programming PGMs

A PGM is a programmable output that toggles to its opposite state (i.e. a normally open PGM will close) when a specific event occurs in the system. For example, a PGM can be used to reset smoke detectors, activate strobe lights, open/close garage doors and much more. When a PGM closes, the module supplies a ground to the PGM (transistor PGM), or the link between N.C. and COM is established (Relay PGM), which activates any device or relay connected to it. When a PGM opens, the circuit opens from ground (transistor PGM), or the link between N.O. and COM is established, therefore no power is provided to the devices connected to it.

## PGM Activation Event

The PGM Activation Event determines which event from what source will activate the PGM. The Event Group specifies the event, the Feature Group identifies the source, and the Start # and End # sets the range within the Feature Group (see PGM Programming Table below).

For example, the APR3-PGM4 (See on page 25) can activate PGM1 when the partition is armed by User Access Codes 256 to 260. Therefore:

- Event Group section **[004]** = 010 "Arming with User Code"
- Feature Group section **[005]** = 001 "User Codes 256 to 511"
- Start # section **[006]** = 000 (representing user code 256)
- End # section **[007]** = 004 (representing user code 260)

Enter the sections that correspond to the Event Group, Feature Group, Start # and End # of the desired PGM and enter the data as required.

## PGM Deactivation Option

Once the PGMs are activated, they can deactivate when another event occurs or after a period of time. The PGM Deactivation Option determines which method is used, the PGM Deactivation Event or the PGM Timer. Enter the section that corresponds to the desired PGM and enable or disable the option.

## PGM Deactivation Event

When the PGM Deactivation Option (see above) is disabled, the PGM Deactivation Event determines which event from what source will return the PGM to its original state. The Event Group specifies the event, the Feature Group identifies the source, and the Start # and End # determine the range within the Feature Group. The complete PGM Programming Table appears below.

For example, the APR3-PGM4 (See on page 25) can deactivate PGM1 when zone 3 opens. Therefore:

- Event Group section **[008]** = 001 "Zone is Open"
- Feature Group section **[009]** = 000 "Zone Numbers"
- Start # section **[010]** = 003
- End # section **[011]** = 003

Enter the sections that correspond to the Event Group, Feature Group, Start # and End # of the desired PGM and enter the data as required.

## PGM Programming Table

		Event Group	Feature Group	Start #	End #
PGM Activation Event	PGM	___/___/___	___/___/___	___/___/___	___/___/___
PGM Deactivation Event	PGM	___/___/___	___/___/___	___/___/___	___/___/___

Event Group	Event	Feature Group	Feature	Start #	End #
000	Zone is OK	000 255 = any Zone #	Zone Numbers	001 to 096	001 to 096
001	Zone is Open			001 to 096	001 to 096
002	Zone is Tampered			001 to 096	001 to 096
003	Zone is in Fire Loop Trouble			001 to 096	001 to 096

Event Group	Event	Feature Group	Feature	Start #	End #
<b>004</b>	<i>Non-reportable Event</i>	<b>000</b>	TLM Trouble (see NOTE 3 on page 58)	000	000
			Smoke detector reset	001	001
			Arm with no entry delay	002	002
			Arm in Stay mode	003	003
			Arm in Away mode	004	004
			Full arm when in Stay mode	005	005
			Voice module access	006	006
			Remote control access	007	007
			PC Fail to communicate	008	008
			Midnight	009	009
			NEware User Login	010	010
			NEware User Logout	011	011
			User Initiated Callup	012	012
			Force Answer	013	013
			Force Hangup	014	014
<b>255</b>	Any non-reportable event	Not Used	Not Used		
<b>005</b>	<i>User Code entered on Keypad</i>	<b>000</b>	User Codes 000 to 255	000 to 255	000 to 255
		<b>001</b>	User Codes 256 to 511	000 to 255	000 to 255
		<b>002</b>	User Codes 512 to 767	000 to 255	000 to 255
		<b>003</b>	User Codes 768 to 999	000 to 231	000 to 231
		<b>255</b>	Any User Code	Not Used	Not Used
<b>006</b>	<i>User/Card Access on door</i>	<b>000</b>	Door Numbers	001 to 032	001 to 032
		<b>255</b>	Any door number	Not Used	Not Used
<b>007</b>	<i>Bypass Programming Access</i>	<b>000</b>	One-touch Bypass Programming	000	000
		<b>000</b>	User Codes 001 to 255	001 to 255	001 to 255
		<b>001</b>	User Codes 256 to 511	000 to 255	000 to 255
		<b>002</b>	User Codes 512 to 767	000 to 255	000 to 255
		<b>003</b>	User Codes 768 to 999	000 to 231	000 to 231
<b>255</b>	Any User Code	Not Used	Not Used		
<b>008</b>	<i>TX Delay Zone Alarm</i>	<b>000</b>	Zone Numbers	001 to 096	001 to 096
		<b>255</b>	Any zone number	Not Used	Not Used
<b>009</b>	<i>Arming with Master</i>	<b>000</b>	User Codes 001 to 255	001 to 255	001 to 255
		<b>001</b>	User Codes 256 to 511	000 to 255	000 to 255
		<b>002</b>	User Codes 512 to 767	000 to 255	000 to 255
		<b>003</b>	User Codes 768 to 999	000 to 231	000 to 231
		<b>255</b>	Any User Code	Not Used	Not Used
<b>010</b>	<i>Arming with User Code</i>	<b>000</b>	User Codes 001 to 255	001 to 255	001 to 255
		<b>001</b>	User Codes 256 to 511	000 to 255	000 to 255
		<b>002</b>	User Codes 512 to 767	000 to 255	000 to 255
		<b>003</b>	User Codes 768 to 999	000 to 231	000 to 231
		<b>255</b>	Any User Code	Not Used	Not Used
<b>011</b>	<i>Arming with Keypad</i>	<b>000</b>	Keypad numbers	001 to 032	001 to 032
		<b>255</b>	Any keypad number	Not Used	Not Used

Event Group	Event	Feature Group	Feature	Start #	End #
012	<i>Special Arming</i>	000	Auto Arming	000	000
			Arming by WinLoad	001	001
			Late to Close	002	002
			No Movement Arming	003	003
			Partial Arming	004	004
			One-touch Arming	005	005
			Future Use	006	006
			Future Use	007	007
		(InTouch) Voice Module Arming	008	008	
		255	Any special arming event	Not Used	Not Used
013	<i>Disarm with Master</i>	000	User Codes 001 to 255	001 to 255	001 to 255
		001	User Codes 256 to 511	000 to 255	000 to 255
		002	User Codes 512 to 767	000 to 255	000 to 255
		003	User Codes 768 to 999	000 to 231	000 to 231
		255	Any User Code	Not Used	Not Used
014	<i>Disarm with User Code</i>	000	User Codes 001 to 255	001 to 255	001 to 255
		001	User Codes 256 to 511	000 to 255	000 to 255
		002	User Codes 512 to 767	000 to 255	000 to 255
		003	User Codes 768 to 999	000 to 231	000 to 231
		255	Any User Code	Not Used	Not Used
015	<i>Disarm with Keypad</i>	000	Keypad numbers	001 to 032	001 to 032
		255	Any keypad	Not Used	Not Used
016	<i>Disarm after alarm with Master</i>	000	User Codes 001 to 255	001 to 255	001 to 255
		001	User Codes 256 to 511	000 to 255	000 to 255
		002	User Codes 512 to 767	000 to 255	000 to 255
		003	User Codes 768 to 999	000 to 231	000 to 231
		255	Any User Code	Not Used	Not Used
017	<i>Disarm after alarm with User Code</i>	000	User Codes 001 to 255	001 to 255	001 to 255
		001	User Codes 256 to 511	000 to 255	000 to 255
		002	User Codes 512 to 767	000 to 255	000 to 255
		003	User Codes 768 to 999	000 to 231	000 to 231
		255	Any User Code	Not Used	Not Used
018	<i>Disarm after alarm with Keypad</i>	000	Keypad numbers	001 to 032	001 to 032
		255	Any keypad	Not Used	Not Used
019	<i>Alarm Cancelled with Master</i>	000	User Codes 001 to 255	001 to 255	001 to 255
		001	User Codes 256 to 511	000 to 255	000 to 255
		002	User Codes 512 to 767	000 to 255	000 to 255
		003	User Codes 768 to 999	000 to 231	000 to 231
		255	Any User Code	Not Used	Not Used
020	<i>Alarm Cancelled with User Code</i>	000	User Codes 001 to 255	001 to 255	001 to 255
		001	User Codes 256 to 511	000 to 255	000 to 255
		002	User Codes 512 to 767	000 to 255	000 to 255
		003	User Codes 768 to 999	000 to 231	000 to 231
		255	Any User Code	Not Used	Not Used
021	<i>Alarm Cancelled with Keypad</i>	000	Keypad numbers	001 to 032	001 to 032
		255	Any keypad	Not Used	Not Used

Event Group	Event	Feature Group	Feature	Start #	End #
<b>022</b>	<i>Special Disarm Events</i>	<b>000</b>	Auto Arm Cancelled	000	000
			One-touch Stay/Instant Disarm	001	001
			Disarming with WinLoad	002	002
			Disarming with WinLoad after alarm	003	003
			WinLoad cancelled alarm	004	004
			Future Use	005	005
			Future Use	006	006
			Future Use	007	007
			(InTouch) Voice Module Disarming	008	008
<b>255</b>	Any special disarm event	Not Used	Not Used		
<b>023</b>	<i>Zone Bypassed</i>	<b>000</b> <b>255 = any zone #</b>	Zone Numbers	001 to 096	001 to 096
<b>024</b>	<i>Zone in Alarm</i>			001 to 096	001 to 096
<b>025</b>	<i>Fire Alarm</i>			001 to 096	001 to 096
<b>026</b>	<i>Zone Alarm Restore</i>			001 to 096	001 to 096
<b>027</b>	<i>Fire Alarm Restore</i>			001 to 096	001 to 096
<b>028</b>	<i>Early to Disarm by User</i>			<b>000</b>	User Codes 001 to 255
		<b>001</b>	User Codes 256 to 511	000 to 255	000 to 255
		<b>002</b>	User Codes 512 to 767	000 to 255	000 to 255
		<b>003</b>	User Codes 768 to 999	000 to 231	000 to 231
		<b>255</b>	Any User Code	Not Used	Not Used
<b>029</b>	<i>Late to Disarm by User</i>	<b>000</b>	User Codes 001 to 255	001 to 255	001 to 255
		<b>001</b>	User Codes 256 to 511	000 to 255	000 to 255
		<b>002</b>	User Codes 512 to 767	000 to 255	000 to 255
		<b>003</b>	User Codes 768 to 999	000 to 231	000 to 231
		<b>255</b>	Any User Code	Not Used	Not Used
<b>030</b>	<i>Special Alarm</i>	<b>000</b>	Emergency Panic (Keys 1 & 3)	000	000
			Medical Panic (Keys 4 & 6)	001	001
			Fire Panic (Keys 7 & 9)	002	002
			Recent Closing	003	003
			Police Code	004	004
			Global Shutdown	005	005
			<b>255</b>	Any special alarm event	Not Used
<b>031</b>	<i>Duress Alarm by User</i>	<b>000</b>	User Codes 001 to 255	001 to 255	001 to 255
		<b>001</b>	User Codes 256 to 511	001 to 255	001 to 255
		<b>002</b>	User Codes 512 to 767	001 to 255	001 to 255
		<b>003</b>	User Codes 768 to 999	001 to 231	001 to 231
		<b>255</b>	Any User Code	Not Used	Not Used
<b>032</b>	<i>Zone Shutdown</i>	<b>000</b> <b>255 = any zone #</b>	Zone Numbers	001 to 096	001 to 096
<b>033</b>	<i>Zone Tamper</i>			001 to 096	001 to 096
<b>034</b>	<i>Zone Tamper Restore</i>			001 to 096	001 to 096
<b>035</b>	<i>Special Tamper</i>			000	000
<b>036</b>	<i>Trouble Event</i>	<b>000</b>	TLM Trouble (see NOTE 2 on page 58)	000	000
			AC Failure	001	001
			Battery Failure	002	002
			Auxiliary Current Limit	003	003
			Bell Current Limit	004	004
			Bell Absent	005	005
			Clock Trouble	006	006
			Global Fire Loop	007	007
			<b>255</b>	Any trouble event	Not Used

Event Group	Event	Feature Group	Feature	Start #	End #
037	<i>Trouble Restore</i>	000	TLM Trouble	000	000
			AC Failure	001	001
			Battery Failure	002	002
			Auxiliary Current Limit	003	003
			Bell Current Limit	004	004
			Bell Absent	005	005
			Clock Trouble	006	006
			Global Fire Loop	007	007
			255	Any trouble restore event	Not Used
038	<i>Module Trouble</i>	000	Combus Fault	000	000
			Module Tamper	001	001
			ROM/RAM error	002	002
			TLM Trouble	003	003
			Fail to Communicate	004	004
			Printer Fault	005	005
			AC Failure	006	006
			Battery Failure	007	007
			Auxiliary Failure	008	008
255	Any module trouble	Not Used	Not Used		
039	<i>Module Trouble Restore</i>	000	Combus Fault	000	000
			Module Tamper	001	001
			ROM/RAM error	002	002
			TLM Trouble	003	003
			Fail to Communicate	004	004
			Printer Fault	005	005
			AC Failure	006	006
			Battery Failure	007	007
			Auxiliary Failure	008	008
255	Any module trouble restore event	Not Used	Not Used		
040	<i>Fail to Communicate on telephone Number</i>	000	Telephone Number	001 to 004	001 to 004
		255	Any telephone number	Not Used	Not Used
041	<i>Low Battery on Zone</i>	000 255 = any Zone #	Zone Numbers	001 to 096	001 to 096
042	<i>Zone Supervision Trouble</i>			001 to 096	001 to 096
043	<i>Low Battery on Zone Restored</i>			001 to 096	001 to 096
044	<i>Zone Supervision Trouble Restored</i>			001 to 096	001 to 096
045	<i>Special Events</i>			000	Power up after total power down
045	<i>Special Events</i>	000	Software reset (Watchdog)	001	001
			Test Report	002	002
			Future Use	003	003
			WinLoad In (connected)	004	004
			WinLoad Out (disconnected)	005	005
			Installer in programming	006	006
			Installer out of programming	007	007
255	Any special event	Not Used	Not Used		
046	<i>Early to Arm by User</i>	000	User Codes 001 to 255	001 to 255	001 to 255
		001	User Codes 256 to 511	000 to 255	000 to 255
		002	User Codes 512 to 767	000 to 255	000 to 255
		003	User Codes 768 to 999	000 to 231	000 to 231
		255	Any User Code	Not Used	Not Used



Event Group	Event	Feature Group	Feature	Start #	End #
<b>047</b>	<i>Late to Arm by User</i>	<b>000</b>	User Codes 001 to 255	001 to 255	001 to 255
		<b>001</b>	User Codes 256 to 511	000 to 255	000 to 255
		<b>002</b>	User Codes 512 to 767	000 to 255	000 to 255
		<b>003</b>	User Codes 768 to 999	000 to 231	000 to 231
		<b>255</b>	Any User Code	Not Used	Not Used
<b>048</b>	<i>Utility Key</i>	<b>000</b>	Utility Key 001 to 064 <sup>†</sup>	001 to 064	001 to 064
		<b>255</b>	Any Utility Key <sup>†*</sup>	Not Used	Not Used
<b>049</b>	<i>Request for Exit</i>	<b>000</b> <b>255 = any Door Number</b>	Door Numbers	001 to 032	001 to 032
<b>050</b>	<i>Access Denied</i>			001 to 032	001 to 032
<b>051</b>	<i>Door Left Open Alarm</i>			001 to 032	001 to 032
<b>052</b>	<i>Door Forced Alarm</i>			001 to 032	001 to 032
<b>053</b>	<i>Door Left Open Restore</i>			001 to 032	001 to 032
<b>054</b>	<i>Door Forced Open Restore</i>			001 to 032	001 to 032
<b>055</b>	<i>Intellizone Triggered</i>			<b>000</b>	Zone Numbers
		<b>255</b>	Any zone number	Not Used	Not Used
<b>056 to 061</b>	<i>Future Use</i>	<b>Future Use</b>	<b>Future Use</b>	<b>Future Use</b>	<b>Future Use</b>
<b>062</b>	<i>Access Granted to User</i>	<b>000</b>	User Codes 001 to 255	001 to 255	001 to 255
		<b>001</b>	User Codes 256 to 511	000 to 255	000 to 255
		<b>002</b>	User Codes 512 to 767	000 to 255	000 to 255
		<b>003</b>	User Codes 768 to 999	000 to 231	000 to 231
		<b>255</b>	Any User Code	Not Used	Not Used
<b>063</b>	<i>Access Denied to User</i>	<b>000</b>	User Codes 001 to 255	001 to 255	001 to 255
		<b>001</b>	User Codes 256 to 511	000 to 255	000 to 255
		<b>002</b>	User Codes 512 to 767	000 to 255	000 to 255
		<b>003</b>	User Codes 768 to 999	000 to 231	000 to 231
		<b>255</b>	Any User Code	Not Used	Not Used

†: see page 58

\*: see page 58

<b>064</b>	<i>Status 1</i>	<b>See Note 1 on page 58</b>	Armed	000	000
			Force Armed	001	001
			Stay Armed	002	002
			Instant Armed	003	003
			Strobe Alarm	004	004
			Silent Alarm	005	005
			Audible Alarm	006	006
			Fire Alarm	007	007
<b>065</b>	<i>Status 2</i>	<b>See Note 1 on page 58</b>	Ready	000	000
			Exit Delay	001	001
			Entry Delay	002	002
			System in Trouble	003	003
			Alarm in Memory	004	004
			Zones Bypassed	005	005
			Bypass, Master, Installer Programming	006	006
			Keypad Lockout	007	007

Event Group	Event	Feature Group	Feature	Start #	End #
066	Status 3	See Note 1 on page 58	Intellizone Delay Engaged (see Note 4 on page 58)	000	000
			Fire Delay Engaged	001	001
			Auto Arm	002	002
			Arming with Voice Module (set until Exit Delay finishes)	003	003
			Tamper	004	004
			Zone Low Battery	005	005
			Fire Loop Trouble	006	006
			Zone Supervision Trouble	007	007
067	Future Use	Future Use	Future Use	Future Use	Future Use
070	Clock	N/A		Hour	Minutes

**NOTE 1:** 000 = Occurs in all partitions enabled in the system (refer to the appropriate control panel *Programming Guide*).

001 = Partition 1 003 = Partition 3 005 = Partition 5 (EVO192 only) 007 = Partition 7 (EVO192 only)

002 = Partition 2 004 = Partition 4 006 = Partition 6 (EVO192 only) 008 = Partition 8 (EVO192 only)

255 = Occurs in at least one partition enabled in the system.

**NOTE 2:** This TLM trouble event can only be used with EVO641R control panels that have two dialers.

**NOTE 3:** This TLM trouble event can only be used with EVO48 control panels or EVO641R control panels that have one dialer.

**NOTE 4:** This event cannot be used for a module's PGM programming.

\*: If a Keyswitch Input is used, the input must be defined as "Generates a Utility Key Event on Open" or "Generates a Utility Key Event on Open and Close". If a remote control is used, the remote control button must be defined as a Utility Key button.

\*\*.: Actions that Activate a Utility Key Event

Utility Key Event	Actions			
	Keypad Utility Keys	Keyswitch Inputs (definition = [3])	Keyswitch Inputs (definition = [4])	Remote Control
Utility Key Event 1	[1] & [2]	KS** Input 1 opens	KS** Input 1 opens	Utility Key 1 RC button <sup>‡</sup>
Utility Key Event 2	[4] & [5]	KS** Input 2 opens	KS** Input 1 closes	Utility Key 2 RC button <sup>‡</sup>
Utility Key Event 3	[7] & [8]	KS** Input 3 opens	KS** Input 2 opens	Utility Key 3 RC button <sup>‡</sup>
Utility Key Event 4	[CLEAR] & [0] or [*] & [0]	KS** Input 4 opens	KS** Input 2 closes	Utility Key 4 RC button <sup>‡</sup>
Utility Key Event 5	[2] & [3]	KS** Input 5 opens	KS** Input 3 opens	Utility Key 5 RC button <sup>‡</sup>
Utility Key Event 6	[5] & [6]	KS** Input 6 opens	KS** Input 3 closes	N/A
Utility Key Event 7	[8] & [9]	KS** Input 7 opens	KS** Input 4 opens	N/A
Utility Key Event 8	[0] & [ENTER] or [0] & [#]	KS** Input 8 opens	KS** Input 4 closes	N/A
Utility Key Event 9	N/A	KS** Input 9 opens	KS** Input 5 opens	N/A
Utility Key Event 10	N/A	KS** Input 10 opens	KS** Input 5 closes	N/A
Utility Key Event 11	N/A	KS** Input 11 opens	KS** Input 6 opens	N/A
Utility Key Event 12	N/A	KS** Input 12 opens	KS** Input 6 closes	N/A
Utility Key Event	Actions			
	Keypad Utility Keys	Keyswitch Inputs (definition = [3])	Keyswitch Inputs (definition = [4])	Remote Control
Utility Key Event 13	N/A	KS** Input 13 opens	KS** Input 7 opens	N/A
Utility Key Event 14	N/A	KS** Input 14 opens	KS** Input 7 closes	N/A
Utility Key Event 15	N/A	KS** Input 15 opens	KS** Input 8 opens	N/A
Utility Key Event 16	N/A	KS** Input 16 opens	KS** Input 8 closes	N/A
Utility Key Event 17	N/A	KS** Input 17 opens	KS** Input 9 opens	N/A
Utility Key Event 18	N/A	KS** Input 18 opens	KS** Input 9 closes	N/A
↓	N/A	↓	↓	N/A
Utility Key Event 31	N/A	KS** Input 31 opens	KS** Input 16 opens	N/A
Utility Key Event 32	N/A	KS** Input 32 opens	KS** Input 16 closes	N/A
Utility Key Event 33	N/A	N/A	KS** Input 17 opens	N/A
Utility Key Event 34	N/A	N/A	KS** Input 17 closes	N/A
i	N/A	N/A	i	N/A
Utility Key Event 63	N/A	N/A	KS** Input 32 opens	N/A
Utility Key Event 64	N/A	N/A	KS** Input 32 closes	N/A

\*\* Keyswitch

<sup>‡</sup> Refer to the Magellan™ Reference and Installation Manual for remote control button programming instructions.

## Warranty

For complete warranty information on this product please refer to the Limited Warranty Statement found on the website [www.paradox.com/](http://www.paradox.com/) terms. Your use of the Paradox product signifies your acceptance of all warranty terms and conditions.

©2002-2007 Paradox Security Systems Ltd. All rights reserved. Specifications may change without prior notice. One or more of the following US patents may apply: 7046142, 6215399, 6111256, 6104319, 5920259, 5886632, 5721542, 5287111, 5119069, 5077549. Canadian and international patents may also apply. Digigard, Digiplex EVO, Grafica, InTouch, Magellan, NEware, Paradoor, and WinLoad are trademarks or registered trademarks of Paradox Security Systems Ltd. or its affiliates in Canada, the United States and/or other countries.

For technical support in Canada or the U.S., call 1-800-791-1919, Monday to Friday from 8:00 a.m. to 8:00 p.m. EST.  
For technical support outside Canada and the U.S., call 00-1-450-491-7444, Monday to Friday from 8:00 a.m. to 8:00 p.m. EST.  
Please feel free to visit our website at [www.paradox.com](http://www.paradox.com).

